


# D

**D80**  
**Manual 1.9 en**



## **General information**

D80 Manual

Version: 1.9 en, 06/2015, D2020.EN .01

Copyright © 2015 by d&b audiotechnik GmbH; all rights reserved.

**Keep this manual with the product or in a safe place so that it is available for future reference.**

We recommend you to regularly check the d&b website for the latest version of this manual.

When reselling this product, hand over this manual to the new customer.

If you supply d&b products, please draw the attention of your customers to this manual. Enclose the relevant manuals with the systems. If you require additional manuals for this purpose, you can order them from d&b.

d&b audiotechnik GmbH  
Eugen-Adolff-Strasse 134, D-71522 Backnang, Germany  
T +49-7191-9669-0, F +49-7191-95 00 00  
docadmin@dbaudio.com, www.dbaudio.com

# IMPORTANT SAFETY INSTRUCTIONS

## Explanation of graphical symbols



The lightning symbol within a triangle is intended to alert the user to the presence of uninsulated "dangerous voltages" within the unit's chassis that may be of sufficient magnitude to constitute a risk of electric shock to humans.



The exclamation point within a triangle is intended to alert the user to the presence of important operating and service instructions in the literature accompanying the product.

## Before using this product, carefully read the applicable items of the following safety instructions.

1. Keep these instructions for future reference.
2. Read these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Keep water or other liquids away from the unit. Do not place liquid filled containers, for example beverages, on top of the unit.
6. Do not operate the unit while it is wet or standing in liquid.
7. Always operate the unit with the chassis ground wire connected to the electrical safety earth. Do not defeat the safety purpose of a grounding-type plug. A grounding-type plug has two blades and a third grounding prong. The third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
8. Do not use this unit if the power cord is damaged or frayed. Protect the power cord from being walked upon or pinched, particularly at the plugs and the point where it exits from the apparatus.
9. The unit is intended for use in a 19" rack. Follow the mounting instructions. When a rack on wheels is used, exercise caution when moving the loaded rack to avoid injury from tipping over.
10. Unplug this apparatus during lightning storms or when unused for long periods of time.
11. Never connect an output pin to any other amplifier input or output pin or to the earth (ground). This may damage the unit or lead to electric shock.
12. Lay all cables connected to the unit carefully so that they cannot be crushed by vehicles or other equipment and that no one can either step on them or trip over them.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way such as:
  - Power-supply cord or plug is damaged.
  - Liquid has been spilled into the unit.
  - An object has fallen into the unit.
  - The unit has been exposed to rain or moisture.
  - The unit does not operate normally.
  - The unit was dropped or the chassis is damaged.
  - Do not remove top or bottom covers. Removal of the covers will expose hazardous voltages. There are no user serviceable parts inside and removal may void the warranty.
14. Use the mains plug as the disconnecting device and keep it readily accessible. If the mains plug is not readily accessible due to mounting in a 19" rack, then the mains plug for the entire rack must be readily accessible.
15. An experienced user must always supervise the equipment, especially if inexperienced adults or minors are using the equipment.

<b>1. Introduction</b>	<b>6</b>
1.1. Intended use	6
1.2. D80 Concept	6
<b>2. Technical specifications</b>	<b>8</b>
<b>3. Scope of supply</b>	<b>10</b>
<b>4. Startup</b>	<b>11</b>
4.1. Overview	11
4.2. Rack mounting and cooling	12
4.3. Connections	14
4.3.1. Mains connection	14
4.3.2. Audio INPUT and LINK connectors	16
4.3.3. Output connectors	17
4.3.4. ETHERNET (Dual Ethernet port)	18
4.3.5. CAN (CAN-Bus)	19
4.4. Controls and indicators	20
4.4.1. Mains power switch	20
4.4.2. Display - User interface	20
4.4.3. Standby mode	21
4.4.4. Mute functions	22
<b>5. User interface</b>	<b>23</b>
5.1. Operating concept	23
5.2. Screen layout and conventions	24
5.3. Screen items and views	24
5.3.1. Function buttons	24
5.3.2. Navigation buttons	24
5.3.3. Input fields	25
5.3.4. Input masks	25
5.3.5. Information fields	25
<b>6. Home screen</b>	<b>26</b>
6.1. Header area - Device	27
6.2. Data area - Channel strip(s)	27
<b>7. Channel strip</b>	<b>28</b>
<b>8. Basic settings - Quick reference</b>	<b>30</b>
<b>9. Device setup</b>	<b>32</b>
9.1. Device name	33
9.2. Input	34
9.2.1. Input mode	34
9.3. Output	36
9.3.1. Output mode	37
9.4. Remote	41
9.4.1. IP settings	41
9.4.2. Remote ID	42
9.5. More	42
9.5.1. Preferences	42
9.5.1.1. Display	43
9.5.1.2. Lock	43
9.5.1.3. Preferences/More	45
9.5.1.3.1. System reset	46
9.5.2. Info	46
9.5.3. Levels	47
9.5.4. Mains current limiter (MCL)	48
9.5.5. AmpPresets	49

9.5.6. Scope.....	50
<b>10. Channel setup.....</b>	<b>51</b>
10.1. Channel name.....	52
10.2. Configuration switches - Filter_1, _2, _3.....	53
10.3. Level.....	53
10.4. EQ - Equalizer .....	53
10.5. DLY - Delay.....	56
10.6. Input routing.....	56
10.7. System check/LM.....	57
10.7.1. System check.....	57
10.7.2. Load monitoring (LM).....	58
10.8. Speaker.....	59
10.8.1. ArrayProcessing (AP).....	61
10.8.2. LoadMatch.....	62
10.8.3. LINEAR setup.....	63
10.9. Frequency generator - Freq. gen.....	63
<b>11. Web Remote interface.....</b>	<b>65</b>
<b>12. Operation (Hardware references).....</b>	<b>68</b>
12.1. Power supply.....	68
12.1.1. Active Power Factor Correction (PFC).....	68
12.1.2. Automatic mains range selection.....	68
12.1.3. Mains voltage monitoring.....	68
12.1.4. Mains inrush current limiter.....	69
12.1.5. Mains supply requirements.....	69
12.1.6. Generator operation/UPS requirements.....	70
12.2. Power amplifiers.....	70
12.3. Cooling fans.....	71
12.4. Current/power draw and thermal dissipation.....	71
<b>13. Service/Maintenance and care.....</b>	<b>73</b>
13.1. Service.....	73
13.2. Maintenance and care.....	73
13.2.1. Touch screen cleaning.....	73
13.2.2. Touch screen calibration.....	74
<b>14. Manufacturer's Declarations.....</b>	<b>75</b>
14.1. EU declaration of conformity (CE symbol).....	75
14.2. WEEE Declaration (Disposal).....	75
14.3. Licenses and Copyright.....	75
<b>15. Appendix.....</b>	<b>76</b>
15.1. System check - References.....	76
15.2. Max. number of cabinets operated in parallel.....	78
15.3. Error messages.....	80

# 1. Introduction

## 1.1. Intended use

The d&b D80 amplifier is designed for mobile applications and intended to be used with all current d&b loudspeakers. A LINEAR setup is available allowing the D80 to be used as a linear power amplifier.

---


## NOTICE!

---


The device complies with the electromagnetic compatibility requirements of EN 55103 (product family standard for audio, video, audio-visual and entertainment lighting control apparatus for professional use) for the environments E1 (residential), E2 (business and commercial), E3 (outdoor use in urban areas) and E4 (outdoor use in rural areas).

Acoustic interference and malfunctions may occur if the unit is operated in the immediate vicinity of high-frequency transmitters (e.g. wireless microphones, mobile phones, etc.). Damage to the device is unlikely, but cannot be excluded.

---



**D80 Front view**




**D80 User interface**

## 1.2. D80 Concept

The D80 amplifier represents the next generation of high power four channel Class D amplifiers. It is developed and manufactured by d&b using Digital Signal Processing (DSP) to incorporate loudspeaker specific configurations and user definable setups, equalization and delay functions. The amplifier is designed to fully drive all d&b loudspeakers and provide comprehensive management and protection capabilities. This high performance amplifier provides the power density required for both touring and installation purposes while the powerful signal processing extends the level of functionality of the on-board features.

The user interface of the amplifier consists of two elements: a color TFT touch screen providing visual information and quick access to the amplifier settings and a rotary encoder on the front panel for data input purposes. To allow ease of operation when the amplifier is below eye level, the front panel and the integrated display are tilted upwards. As a result, the front panels of multiple amplifiers on top of each other within a rack integrate to form one large control surface.

The user definable equalizer features two independent 16-band EQ groups within each channel. These provide parametric, notch, shelving and asymmetric filters as well as a graphic EQ (via the d&b R1 Remote control software V2) allowing instant switching between two EQ curves for comparison. The delay capability covers a range of up to 10 s. All loudspeaker specific functions such as CUT, HFA, HFC, CSA or CPL are available. The DSP unit of the amplifier has a fixed latency of 0.3 ms.



**D80 Rear view**

The amplifier enables up to four input channels, which may be four analog inputs, two analog and two AES channels or four AES channels. Each input channel can be routed to any of the output channels A to D. XLR connectors 2 and 4 of the D80 can be used as either digital or analog inputs, connectors 1 and 3 are analog inputs. Link outputs are supplied for all inputs. This 1:1 ratio of inputs to amplifier output channels increases flexibility of application, particularly for use as monitor, frontfill or effect channels.

The D80 amplifier outputs are optionally NL4 or EP5 connectors plus one centered NL8 connector with all pins driven. The latter serves as an interface to a rack panel or to loudspeaker multicore and breakout adapters. To simplify configuration, the output mode of the amplifier can be configured like a set of two dual channel amplifiers providing Dual Channel, Mix TOP/SUB or 2-Way Active modes for the left and the right channels A/B and C/D, respectively.

For applicable loudspeakers, d&b LoadMatch enables the D80 amplifier to electrically compensate for the properties of the cable used to connect the loudspeakers to the amplifier output. This function which covers a bandwidth of up to 20 kHz preserves the tonal balance when cable lengths of up to 70 m (230 ft) are used. Due to its design LoadMatch does not require additional wires and is therefore applicable with any connector type used. To provide optimum compensation, cable length and cross-sectional data as well as the number of loudspeakers connected to the amplifier channel can be entered on the amplifier.

The D80 utilizes a switch mode power supply with active Power Factor Correction (PFC) to produce a clean current draw and ensure stable and efficient performance under adverse mains conditions. The high power capabilities provide increased power to fully drive all applicable d&b loudspeaker cabinets and sufficient headroom for any future systems.

Remote control and full system integration are realized using the d&b ArrayCalc simulation software and R1 Remote control software V2. The D80 amplifier includes two Ethernet ports on etherCON connectors to enable daisy chaining. Both Ethernet and dbCAN protocols are incorporated. The Ethernet protocol implemented in the d&b R1 Remote control software V2 and the D80 amplifier is a protocol developed by the OCA Alliance (Open Control Architecture Alliance), of which d&b is a founding member. For further details, please refer to the OCA website: [www.oca-alliance.com](http://www.oca-alliance.com).

## 2. Technical specifications

### Audio data (linear setting with subsonic filter)

Maximum output power per channel (THD + N < 0.5%, all channels driven) .....	.....
CF = 6 dB @ 4/8 ohms .....	4 x 2600/2000 W
CF = 12 dB @ 4/8 ohms .....	4 x 4000/2000 W
Maximum output voltage .....	180 V
Frequency response (-1 dB) .....	35 Hz - 20 kHz
THD+N 20 Hz - 20 kHz, 600 W @ 4 ohms) .....	< 0.5%
S/N ratio (unweighted, RMS) .....	.....
Analog input .....	> 110 dB
Digital input .....	> 114 dB
Damping factor (20 Hz - 200 Hz into 4 ohms) .....	> 100
Crosstalk (20 Hz - 20 kHz) .....	< -70 dB
Gain (Linear mode @ 0 dB) .....	31 dB

### Protection circuits

Mains inrush current limiter .....	13 A <sub>RMS</sub> @ 230 VAC
.....	22 A <sub>RMS</sub> @ 120 VAC
.....	27 A <sub>RMS</sub> @ 100 VAC
Ground fault protection .....	.....
Output current limitation/protection .....	65 A / 75 A
Output DC offset protection .....	10 V
Output HF Voltage Limiter .....	60 V @ 10 kHz
Output pop-noise suppression .....	.....
Mains Current Limitation (MCL) .....	95 to 50 % of 16 / 30 A
Overvoltage protection .....	Up to 400 VAC
Self-resetting overtemperature protection .....	.....

### Power supply

Autosensing switched mode power supply with active power factor correction (PFC) .....	.....
Mains connector .....	powerCON-HC
Rated mains voltage .....	208 to 240 V, 50 - 60 Hz
.....	high range
.....	100 to 127 V, 50 - 60 Hz
.....	low range
Mains fuse .....	internal

### Power consumption (typical values)

Standby .....	9 W
Idle .....	180 W
Max. power consumption (short term RMS) .....	7000 W

### Audio input connectors

INPUT analog (A1 - A4) .....	3 pin XLR female
Pin assignment .....	1 = GND, 2 = pos., 3 = neg.
Input impedance .....	38 kOhms, electronically balanced
Common mode rejection (CMRR @ 100 Hz/10 kHz) .....	> 70 / 50 dB
Maximum input level (balanced/unbalanced) .....	+25 / 17 dBu
.....	+27 dBu @ 0 dBFS
LINK analog (A1 - A4) .....	3 pin XLR male
Pin assignment .....	1 = GND, 2 = pos., 3 = neg.
.....	parallel to input
INPUT digital (D1/2, D3/4) .....	3 pin XLR female, AES 3
Pin assignment .....	1 = GND, 2 = AES Signal, 3 = AES Signal
Input impedance .....	110 ohms, transformer balanced
Sampling .....	48 / 96 kHz / 2 Ch/n
Synchronization .....	Word-Sync: PLL-locked to source (slave mode)
LINK digital (Output) .....	3 pin XLR male
.....	electronically balanced
.....	analog signal buffering (refresh), power fail relay (Bypass)

### Output connectors

SPEAKER OUTPUTS A/B/C/D .....	4 x NL4
.....	optional: 4 x EP5
4 CHANNEL OUTPUT .....	1 x NL8

### Network connectors

CAN .....	2 x RJ 45 parallel
ETHERNET .....	2 x etherCON®
.....	Dual Ethernet port with built-in 2-port Ethernet switch
.....	10/100 Mbit

### Controls and indicators

POWER .....	Mains power switch
SCROLL/EDIT .....	Digital rotary encoder
Display .....	TFT color touch screen, 3.5" / 320 x 240 Pixel



## Digital Signal Processing

System start-up time .....	17 sec.
Sampling rate .....	96 kHz / 27 Bit ADC / 24 Bit DAC
Latency analog input .....	0.3 msec.
Latency digital input (AES) .....	0.3 msec.
.....	48 kHz / 96 kHz
Input dynamic .....	> 127 dB
ADC dynamic .....	> 110 dB
DAC dynamic .....	> 110 dB
Equalizer .....	two user definable 16-band equalizers
.....	Filter types: PEQ/Notch/HiShlv/LoShlv/Asym
Delay .....	0.3 msec. - 10 sec.
Frequency generator .....	Pink noise or Sine wave 10 Hz - 20 kHz

## Operating conditions


Temperature range* .....	-10 °C ... +40 °C / +14 °F ... +104 °F
.....	* continuous operation
Temperature range** .....	-10 °C ... +50 °C / +14 °F ... +122 °F
.....	** reduced output power or short term operation
Storage temperature .....	-20 °C ... +70 °C / -4 °F ... +158 °F
Humidity (rel.), long term average .....	70%

## Fan noise emission

Rack mounted, measured on axis, 1 m to front panel, A-weighting .....	
Idle .....	34 dB(A)
.....	Ambient temperature 22 °C / 71.6 °F
Max. RPM .....	49 dB(A)


## Dimensions and weight

Height x width x depth .....	2 RU x 19" x 530.5 mm
.....	2 RU x 19" x 20.9"
Weight .....	19 kg / 42 lb



D80 enclosure dimensions in mm [inch]

### 3. Scope of supply



Before starting up the device, please verify the shipment for completeness and proper condition of the items.


If there is any sign of obvious damage to the unit and/or the power cord, do not operate the unit and contact your local dealer from whom you received it.

Pos.	Qty.	d&b Code	Description
[1]	1	Z2710	d&b D80 Amplifier, dependent on chosen output option (NL4 or EP5 output connectors).
Including:			
[2]	1	Z2620.xxx	Power cord D80 (specific to country).
[3]	1	K6007.050	RJ 45 Patch cable, 0.5 m (1.6 ft) CAT 6/AWG 24-STP (shielded twisted pair) to be used for daisy chaining multiple amplifiers within a rack.
[4]	1	Z6116	RJ 45 M Terminator for terminating the last device of a CAN-Bus segment.
[5]	1	D2020.EN .01	D80 Manual.

## 4. Startup

### 4.1. Overview

#### Connections



**[1]** Mains connector socket.  
Refer to ⇒ Chapter 4.3.1. "Mains connection" on page 14 and ⇒ Chapter 12.1.5. "Mains supply requirements" on page 69.


**[3]** Output connector panel, dependent on chosen output option (NL4 or EP5 output connectors).  
Refer to ⇒ Chapter 4.3.3. "Output connectors" on page 17.

**[2]** Audio INPUT (analog/digital) and LINK connectors.  
Refer to ⇒ Chapter 4.3.2. "Audio INPUT and LINK connectors" on page 16.

**[4]** ETHERNET.  
Refer to ⇒ Chapter 4.3.4. "ETHERNET (Dual Ethernet port)" on page 18.


**[5]** CAN (CAN-Bus).  
Refer to ⇒ Chapter 4.3.5. "CAN (CAN-Bus)" on page 19.

#### Controls and indicators - User interface



**[7]** 3.5" TFT color touch screen.  
**[8]** Rotary encoder SCROLL/EDIT.  
Refer to ⇒ Chapter 4.4. "Controls and indicators" on page 20 and ⇒ Chapter 5. "User interface" on page 23.

**[6]** Mains power switch.  
Refer to ⇒ Chapter 4.4. "Controls and indicators" on page 20, following ⇒ Chapter 4.4.1. "Mains power switch" on page 20.



## 4.2. Rack mounting and cooling

### Rack mounting

The D80 amplifier enclosure is designed to fit standard 19" equipment racks or cabinets.

When specifying a rack, be sure to allow extra depth (150 mm / 6" is usually sufficient) to accommodate the cables and connectors at the rear of the amplifier.


When mounting D80 amplifiers into a 19" rack, do not just rely on fixing and supporting the amplifiers by their front panels using appropriate rack mounting screws and U washers as shown in the graphic opposite. Provide additional support ...

- by fixing the rear-mounted rack ears using appropriate rack mounting screws and U washers as shown in the graphic opposite. This is particularly important when amplifiers are racked up for touring purposes.
- or using shelves fixed to the inner sides of the cabinet or rack.

### Cooling




Thermal conditions are a vital factor to ensure operational safety of the power amplifiers. The D80 amplifier is equipped with three internal fans that draw cool air from the front into the housing and channel the warm air towards the back of the device.

- Please ensure that adequate cool airflow is provided.
- Do not block or cover the front panel air intake or the vents on the rear panel.
- If amplifiers are installed in sealed cabinets (e.g. in fixed installations), use additional fan modules with filters that can be easily replaced without opening the sealed cabinets.
- Do not combine D80 amplifiers with D6 or D12 amplifiers in one rack.
- Do not rack up D80 amplifiers together with other devices producing additional heat with opposing airflows.



### Base heat

Unlike other amplifiers, the D80 produces a base heat of approx: 40 °C (104 °F) in the rear part of the device when idling (On, idling). During operation, this temperature will only increase insignificantly. Please also refer to ⇒ Chapter 12.4. "Current/ power draw and thermal dissipation" on page 71.



### Touring rack assemblies


When using touring rack assemblies such as the d&b Z5330 D80 Touring rack assembly or any other touring rack containing D80 amplifiers, make sure to provide sufficient space of 0.5 m (1.6 ft) at the front and rear of the touring rack to ensure adequate cooling airflow.

D80 Touring rack assemblies can be positioned side by side or stacked.

When combining the Z5330 D80 Touring rack assembly with the Z5310 D12 Touring rack assembly or any other rack assembly that produces an opposing airflow, observe the following restrictions:

- D12/D80 Touring rack assemblies can be positioned side by side.
- Do not stack D80 and D12 Touring racks or any other rack assemblies with opposing airflow.

### 4.3. Connections



#### 4.3.1. Mains connection





#### **WARNING!**

**Potential risk of electric shock.**

The device is a protective class 1 unit. A missing earth (ground) contact may cause dangerous voltages in the housing and controls and may lead to electric shock.

- Connect the unit to mains power supplies with protective earth only.
- If there is any sign of obvious damage to the power cord and/or mains connector, do not use the power cord and replace it before further use.
- Please ensure the mains connector is accessible at any time to disconnect the unit in case of malfunction or danger. If the mains plug is not readily accessible due to mounting in a 19" rack, then the mains plug for the entire rack must be readily accessible.
- Do not connect or disconnect the powerCON® mains connector under load or live.



## NOTICE!




Due to the high power capability of the device, only operate **one device per phase conductor**.

Please also refer to ⇒ Chapter 12.1. "Power supply" on page 68, following ⇒ Chapter 12.1.5. "Mains supply requirements" on page 69.

Mains voltage	Frequency	Current
100/120 V	50/60 Hz	30 A
230/240 V	50/60 Hz	15 - 16 A

Before connecting the device to mains voltage, check that the mains voltage and frequency correspond to the specifications on the rating label next to the mains connector socket on the rear panel of the unit.

A powerCON-HC® mains connector socket **[1]** is fitted on the rear panel and an appropriate power cord **[2]** is supplied.



### 4.3.2. Audio INPUT and LINK connectors

All signal input and link output connectors 1-4 are located on the rear panel.

These can be configured as four analog inputs, two analog and two AES channels or four AES channels (Please refer to ⇒ Chapter 9.2. "Input" on page 34).

Each input channel can be routed to any of the output channels A to D (Please refer to ⇒ Chapter 10.6. "Input routing" on page 56).

#### Analog INPUT and LINK (A1 - A4)

A 3-pin female XLR input connector is provided for each channel. Wired in parallel is a 3-pin male XLR input link connector used to feed the input signal on to the next device in the signal chain.

#### Specifications

Pin assignment.....	1 = GND, 2 = pos., 3 = neg.
Input impedance.....	38 kOhms, electronically balanced
Common mode rejection (CMRR@100 Hz/10 kHz).....	> 70/50 dB
Maximum input level (balanced/unbalanced).....	+25/17 dBu
.....	+27 dBu @ 0 dBFS
LINK analog (A1 - A4).....	3 pin XLR male
.....	parallel to input

#### Digital INPUT and LINK (D1/2 - D3/4)

The input connectors 2 (D1/2) and 4 (D3/4) can be configured as AES/EBU (AES 3) inputs individually.

**Note:** When configuring the digital inputs, the remaining input and link output connectors 1 (A1) and/or 3 (A3) are disabled.

The corresponding digital LINK output (2/4) can be used to feed a refreshed input signal to the next device in the signal chain. The signal shape (the rising and falling edges of the signal) and level are refreshed with an analog buffer amplifier.


A power fail relay is incorporated to prevent interruption of the signal chain should there be a power failure. In this situation, the digital input signal bypasses the analog buffer amplifier and is routed directly to the LINK output.

#### Specifications

Pin assignment.....	1 = GND, 2 = AES Signal, 3 = AES Signal
Input impedance.....	110 ohms, transformer balanced
Sampling.....	48 / 96 kHz / 2 Ch/n
Synchronization.....	Word-Sync: PLL-locked to source (slave mode)
LINK digital (Output).....	3-pin XLR male
.....	electronically balanced
.....	analog signal buffering (refresh)
.....	Power Fail Relay (Bypass)



### 4.3.3. Output connectors





#### WARNING!

Potential risk of electric shock.

The amplifier output pins can carry dangerous voltages.

- Only use isolated loudspeaker cables with correctly fitted connectors.
- Never connect an amplifier output pin to any other input or output connector pin or protective earth (ground).



#### SPEAKER OUTPUTS

Depending on the chosen output option, the amplifier is supplied with four NL4 or EP5 output connectors, one for each amplifier output channel.

Depending on the output mode selected, the appropriate pin assignment of the relevant output connectors is set automatically.

**Note:** A detailed description of the applicable output modes and how to configure the appropriate output mode is given in  $\Rightarrow$  Chapter 9.3.1. "Output mode" on page 37.

For further information regarding the applicable output modes for each loudspeaker system, please refer to the relevant loudspeaker manual.

#### 4 CHANNEL OUTPUT


#### NOTICE!


The 4 CHANNEL OUTPUT connector is only intended as an interface to a rack panel or to loudspeaker multicores and breakout adapters.

Do not connect any loudspeaker cabinets, neither passive nor active systems, to this connector, otherwise there is a risk of damaging the loudspeaker components or the amplifier.

The centered NL8 connector carries the output signals of all four amplifier channels with the following pin assignment:

1+/- = Channel A pos. / neg.	2+/- = Channel B pos. / neg.
3+/- = Channel C pos. / neg.	4+/- = Channel D pos. / neg.





#### 4.3.4. ETHERNET (Dual Ethernet port)

A Dual Ethernet port with a built-in 2-port Ethernet switch (10/100 Mbit/peer-to-peer) is provided enabling remote control via Ethernet and allows the following physical network topologies:

- Star topology
- **Recommended standard,**
- Daisy chain topology
- **For a maximum of three devices,**
- or a combination of both topologies.

**Note:** In a daisy chain topology, if one device fails or is switched off, this also affects all subsequent devices which are then no longer connected to the network either.


A detailed description of remote control via Ethernet is given in the technical information TI 310 (d&b code D5310.EN) which can be downloaded from the d&b website at [www.dbaudio.com](http://www.dbaudio.com).

#### LED indicators


The two LED indicators above the respective connector in use indicate the following states:

- Green** Illuminates permanently when the device is connected to an active network and flashes as long as a data stream is transmitted.
- Yellow**
  - Is off when the speed is 10 Mbit.
  - Illuminates permanently when the speed is 100 Mbit.


#### Network topologies





Star topology



Daisy chain topology for a maximum of three devices



Combined topology



Pin 1: n.c.  
 Pin 2: n.c.  
 Pin 3: n.c.  
**Pin 4: CAN\_H(igh) line**  
**Pin 5: CAN\_L(ow) line**  
 Pin 6: n.c.  
 Pin 7: n.c.  
 Pin 8: n.c.  
**Shield: CAN Ground (PE)**

### 4.3.5. CAN (CAN-Bus)

The device is equipped with a 2-wire serial remote control interface carrying the CAN-Bus signals to enable remote control with the d&b R60 USB to CAN or R70 Ethernet to CAN interfaces.

**Note:** A detailed description of remote control via the d&b Remote network (CAN-Bus) is given in the technical information TI 312 (d&b code D5312.EN) which can be downloaded from the d&b website at [www.dbaudio.com](http://www.dbaudio.com).

All pins of both connectors are wired in parallel allowing either to be used as input or output (daisy chaining) or for terminating the CAN-Bus network.


#### Pin assignment

The pin assignments of both, the RJ 45 sockets and the cable connectors, are shown in the graphic opposite.


**Note:** The connections for the CAN-Bus are referenced to common ground. The "CAN Ground" is routed **via the cable shielding** and is hardwired to PE.

Within the CAN-Bus network, shielded cables and shielded RJ 45 connectors (metal housing) must be used while the cable shielding must be connected to both sides.

#### CAN network topologies





**Daisy chain topology**  
 With R60 USB to CAN interface



**Combined topology**  
 With R70 Ethernet to CAN interface

## 4.4. Controls and indicators



### 4.4.1. Mains power switch

The on/off rotary switch [6] is located on the bottom right of the front panel.


- OFF** Mains isolation is not provided. The internal power supplies are off but stay connected to the mains.
- ON** The unit is switched on and ready for operation.

### 4.4.2. Display - User interface

Operation, configuration and status viewing are all performed via the Display ⇒ User interface.

The user interface consists of a 3.5" TFT color touch screen [7] with a resolution of 320 x 240 pixels and an additional digital rotary encoder [8].

The resistive touch screen responds to pressure and therefore can be operated by a fingertip, even when wearing gloves, or by an appropriate stylus tip (pen).




#### NOTICE!

The touch panel utilizes a thin flexible sheet that may be damaged by sharp objects or heavy treatment.

Due to the wide range of functions the user interface is described separately in more detail in ⇒ Chapter 5. "User interface" on page 23.

However, both the Standby and Mute functions of the D80 are described in the following two sections.



### 4.4.3. Standby mode

To switch the device to Standby mode ... :

1. Tap the «Power» button on the top right of the Home screen. A dialog appears allowing you to either select the Back button (⌂ - cancel), «Mute all» or «Standby».
2. Select «Standby».

When the device is in Standby mode, both the «Power» button on the right and the green Power on indicator on the left are switched off. In addition, on the Device view button, Standby flashes alternating with the Device name.

**Note:** In Standby mode, the user interface of the device is still operable.

3. To repower the unit, tap the «Power» button. Startup time from Standby state is <1 sec.

The operating state (Standby mode) is stored when the «Power» button is set to "Off" and is restored when the «Power» button is set back to "On" again.

In Standby mode, the main power supply and the power amplifiers are switched off to save energy and the loudspeaker outputs are electronically isolated. The display and controls remain active to allow repowering of the device by remote control or by tapping the «Power» button on the Home screen.

**Note:** When the device is set to Standby (or the mains power is switched off), the movement of the loudspeaker cones in the connected cabinets is no longer damped by the power amplifier output. This removal of the damping makes them susceptible to excitation by other loudspeakers in the surroundings. Audible resonances may occur, and even absorption of low frequency sound energy as the undamped loudspeakers act like a "bass trap".

To permanently mute single subwoofer cabinets while others are operated at the same time it is therefore preferable to use the Mute function instead of Standby. However, the Standby mode can be useful with mid/high systems as it removes any residual noise from the system.

#### 4.4.4. Mute functions



The D80 provides two mute functions:

- Individual mute buttons for each channel or pair of channels  
⇒ Channel mute,
- and a master mute function ⇒ «Mute all».


**Note:** The device stores the setting of the mute buttons when the mains power is switched off or disconnected. When the unit is switched on or reconnected, the mute status will be recalled.

#### Channel mute


- ⇒ To mute or unmute a single channel or a pair of channels, simply tap the respective Channel mute button.
- ⇒ The Channel mute button displays the mute status of the relevant channel or pair of channels and the loudspeaker setup loaded.



Channel muted







Channel unmuted



#### Master mute («Mute all»)

1. To mute all channels simultaneously, tap the «Power» button on the top right of the Home screen.
  - ⇒ A dialog appears allowing you to either select the Back button (⏪ - cancel), «Mute all» or «Standby».
2. Select «Mute all».
  - ⇒ To unmute the channels, use the individual Channel mute buttons.

## 5. User interface



### 5.1. Operating concept

The operating concept allows different methods of interaction and configuration.

#### Touch screen in combination with the rotary encoder

This method may preferably be used to define values of input fields such as Gain settings, CPL, Delay or EQ settings.

- Select menus, menu items and/or function elements by tapping the relevant item.
- Enter/edit values by turning the encoder.
- Confirm entered/changed values by tapping the respective item or confirmation button («OK») or pushing the encoder.

#### Rotary encoder only

This method is mainly intended for users who are familiar with the user interfaces of other d&b amplifiers.

- Select menus, menu items and/or function elements by turning the encoder to move the Position cursor to the relevant item.
- Access the selected item or function element by pushing the encoder.
- Enter/edit values by turning the encoder.
- Confirm entered/changed values or leave Edit mode by pushing the encoder.

#### Cursor conventions

The graphical user interface features two types of cursors, the Position and the Edit cursors.

##### Position cursor

The Position cursor marks the selected Menu item by a white frame. Depending on the type of screen item, the Position cursor allows you to either activate a function, navigate through the menu or enter Edit mode ⇒ Edit cursor.




##### Edit cursor

In Edit mode, the Edit cursor is marked by a yellow frame. Turning the encoder to the right (clockwise) increases the current value, turning the encoder to the left (counterclockwise) decreases it.



To leave Edit mode press the encoder or simply tap the respective Menu item again. The color of the frame will change from yellow back to white again ⇒ Position cursor.



**Basic screen layout**

- a) Home screen
- b) Device and Channel setup screens

**5.2. Screen layout and conventions**

The screen layout is split into two main parts, the Header and the Data sections.

**Header** The Header (Headline) indicates which screen is currently selected. In the Device and Channel setup screens, the Header allows direct access to the previous screen (Back button - ◀) or to the Home screen (Home button - 🏠).

**Data** Except for the Home screen, the Data sections of the Channel and Device setup screens are structured in tabs on the right hand side of the screen. The tabbed structure of the screens allows you to directly access the desired subscreens.


**5.3. Screen items and views**

This section describes the different menu items, views and function elements characterizing the user interface of the D80.

**5.3.1. Function buttons**

**Properties:**

- The top left of the button shows the function name while the bottom right shows the status of the function. In addition, the status is also indicated by colors.
- The function is activated by tapping the button on screen or pushing the encoder.
- Functions buttons can also be combined with navigation buttons.



**5.3.2. Navigation buttons**

**Properties:**

- The top right of the button shows the navigation symbol (▶).
- Open the related subscreen by tapping the button on screen or pushing the encoder.







### 5.3.3. Input fields

#### Properties:

- The top left of the button shows the field name while the bottom right shows the value. The value can be edited.
- Select the value by tapping the button on screen or pushing the encoder.
- Edit the value by turning the encoder.


**Note:** The set value will be applied directly.



### 5.3.4. Input masks

#### Properties:

- Appears automatically anytime you need to enter data to define a particular function. The input mask provides you with an alphanumeric or numeric keypad to enter, for example, a device name or a channel name (alphanumeric keypad) or an IP address (numeric keypad).
- Selection and editing is performed using the touch screen or turning and pushing the encoder.



### 5.3.5. Information fields

#### Properties:

Non-selectable/non-editable field for information purposes only.

## 6. Home screen






From the Home screen, the menu structure of the operating software is divided into two main axes, the Device setup and the Channel setup. The navigation buttons allow for direct vertical access to the specific submenus while the tab structure on the right side of each submenu provides a clear horizontal order.

In addition, the Home screen gives direct access to the Remote subscreen.

The Home screen can be accessed from any screen or menu at any level using the Home button (🏠).

Home screen access chart  
Hierarchy level





## 6.1. Header area - Device

(from left to right):

### Power on indicator

**Yellow** Indicates the start up phase of the power supply.

**Green** Indicates that the unit is switched on.

**Red** Indicates a device error.

### Device view button

The device name and the output mode are displayed. This button provides direct access to the Device setup screen.

### ID

The Remote «ID» is displayed. This navigation button also provides direct access to the Remote subscreen.

### Power button

The «Power» button provides the following functions:

 Cancel the sequence.

**Mute all** Master mute.  
To unmute the channels, use the individual Channel mute buttons.


**Standby** In Standby mode the device idles drawing minimal power consumption. Only the most essential functions are provided. The screen and network remain functional.

## 6.2. Data area - Channel strip(s)

The data area features the actual channel strips starting with the input connector and then following the real signal flow from left to right. All vital information is displayed. This includes:

- Input signal present (ISP)
- Input routing
- Channel configuration,
- Controller output signal (OSP)
- Channel mute buttons and status.
- Error messages

## 7. Channel strip




D80 Channel strip block diagram (signal chain)

The channel strip follows the actual signal chain from left to right:

### ISP/OVL

Indicates the following states for both, the analog (**A**) and the digital (**D**) signal inputs:



### Grey

The relevant channel is not available.

### White

The relevant channel is available and an input signal is not present or below  $-30$  dBu.

### Green

**ISP (Input Signal Present)**: Illuminates when the analog input signal exceeds  $-30$  dBu or when the digital input is locked to 48 or 96 kHz and the signal exceeds  $-57$  dBFS.

### Red

**OVL (Overload)**: Illuminates when the analog input signal exceeds 25 dBu or when the digital input signal exceeds  $-2$  dBFS.

### Channel view

The Channel view button displays the Channel name. If no Channel name has been entered, the loudspeaker setup which is currently loaded is displayed. In addition, the activated function elements are indicated. The button provides direct access to the  $\Rightarrow$  Channel setup screen.



### Level

The Level input field allows direct setting of the amplifier's relative input sensitivity in the range of  $-57.5$  dB to  $+6$  dB in steps of 0.5 dB.

In addition, the following indicators are available:



### ISP/OSP/GR/OVL

Indicates whether the DSP receives an input signal and whether the DSP output signal is present (provided the channel is not muted).

- Grey** No signal present.
- Dark green:** Channel input signal present (ISP).
- Bright green:** Controller (DSP) output signal present (OSP).
- Yellow** **GR (Gain Reduction):**  
Illuminates when one limiter reduces the signal by a predefined level (GR ≥ 3 dB).
- Red** **OVL (Overload):**  
Illuminates when ...:
  - any signal within the channel exceeds -2 dBFS.
  - DSP suffers from an internal EQ filter overflow.
  - any limiter causes a gain reduction of 12 dB or more.
  - the output signal is limited to prevent distortion due to output peak current overload of >70 A.




### Channel mute

- ⇒ To mute or unmute a single channel or a pair of channels, simply tap the respective Channel mute button.
- ⇒ The Channel mute button displays the mute status of the relevant channel or pair of channels and the loudspeaker setup loaded.




Channel muted




Channel unmuted



A channel error is indicated on the Channel mute button by an exclamation mark ⇒ .

A corresponding error message is issued on the Channel view button.

## 8. Basic settings - Quick reference



Due to the vast functional range and possible settings of the D80 amplifier, this section is intended as a quick reference to provide you with a systematic procedure for defining the basic settings of the amplifier.

It is advisable to start with the device settings followed by the individual channel settings.

### System reset


Before starting to define the basic settings, perform a system reset.

1. Switch off the device.
2. Press and hold the encoder and repower the device.  
⇒ Long confirmation beep.
3. Release the encoder and briefly press the encoder again within 2 sec.  
⇒ Short confirmation beep.  
The device will boot up and will switch to the Home screen. A corresponding message will be issued:

**All device settings have been cleared**


### 1. Device setup

- ⇒ On the Home screen, tap the Device view button.
- ⇒ This will enter the Device setup subscreen with the «Input» tab being active.



### 2. Input (Input mode / Input routing)

- ⇒ Define your Input mode and Input routing settings for all channels correspondingly.




**Note:** A detailed description of the Input routing is given in the reference chapter of the Channel setup ⇒ Chapter 10.6. "Input routing" on page 56.


A detailed description of the Input mode is given in the reference chapter ⇒ Chapter 9.2. "Input" on page 34.

### 3. Output (Output mode)

- ⇒ Tap the «Output» tab and define your desired output mode settings for each pair of amplifier channels correspondingly.

**Note:** A detailed description of the available output modes is given in the reference chapter ⇒ Chapter 9.3. "Output" on page 36





### Speaker

1. On the bottom left of the «Output» tab, select the «Speaker» navigation button to enter the Speaker setup subscreen.
2. Choose the desired speaker setups for all channels and confirm each selected setup by tapping the «OK» button right next to the «Speaker» selection field.
3. Define the LoadMatch settings, if applicable and desired, correspondingly.
4. After defining all settings, exit the subscreen by tapping the Home button (🏠).

**Note:** A detailed description of the Speaker setup and LoadMatch settings is given in the reference chapter ⇒ Chapter 10.8. "Speaker" on page 59.




### 4. Remote

1. On the Home screen, tap the Device view button to enter the Device setup menu.
2. Tap the «Remote» tab and define your desired Remote settings correspondingly.

**Note:** A detailed description of the remote settings is given in the reference chapter ⇒ Chapter 9.4. "Remote" on page 41.

As all the configurations and settings mentioned above can also be defined remotely, it depends on how you wish to proceed whether defining the Remote settings is the last or the first step when configuring your basic settings.

After defining all settings, exit the subscreen by tapping the Home button (🏠) and carry on with the individual channel settings.



### 5. Channel setup

1. On the Home screen, tap the Channel view button of the first channel (A) or pair of channels (A/B) to enter the Channel setup.
2. Define your individual channel settings such as CUT, HFA, CPL, Level, DLY or EQ for all channels correspondingly.
3. After defining all settings, exit the subscreen by tapping the Home button (🏠).


**Note:** A detailed description of the Input routing is given in the reference chapter ⇒ Chapter 10.6. "Input routing" on page 56.

A detailed description of the Input mode is given in the reference chapter ⇒ Chapter 9.2. "Input" on page 34.



# 9. Device setup

## Device setup access chart

### Hierarchy level







From the Home screen, selecting the Device view button opens the Device setup screen with the «Input» tab being active.

The Device setup screen follows the same layout structure as described above and is split into the Header and the Data sections.

Using the tabbed structure of the Device setup screen provides direct access to the desired subscreens.

### 9.1. Device name


Selecting the centered Information field button («Edit device name») in the header of the device setup screen enables you to enter or edit the device name (maximum length 15 characters).

The input mask which appears allows either lower-case or upper-case characters by toggling the corresponding button («abc») on the bottom left.

Wrong entries can be corrected by tapping the Erase button (X) on the bottom right.

Tapping «OK» on the top right confirms the entry, closes the input mask and switches back to the Device setup screen.

Tapping the Back button (K) on the top left cancels any entry and switches back to the Device setup screen keeping the previous entry.




## 9.2. Input

Selecting the «Input» tab allows you to configure the Input mode for the input connector pairs 1/2 and 3/4 independently to accept either analog or digital input signals.

The operating mode of the corresponding link output connectors 2 and 4 depends on the set input mode.

### 9.2.1. Input mode



Input mode block diagram



### Analog/Analog

Both input connector pairs 1/2 and 3/4 are set to «Analog», an analog audio signal is accepted by inputs 1, 2, 3 and 4.

## Digital/Digital


### NOTICE!

When both input pairs are set to «Digital» and locking to the sync source is not possible, none of the inputs will receive any audio signal.

If two digital signals are used at the same time, these signals must be completely synchronous (i.e. must have the same synchronized sampling rate).

Both input connector pairs 1/2 and 3/4 are set to «Digital», a 2-channel digital audio signal is accepted by inputs 2 and 4 respectively.

The input connectors 1 and 3 are not available.

Locking to either 48 or 96 kHz is indicated below . In this case, the sync source is input 2.


When both input pairs are set to «Digital», either of them can be selected as sync source.

### Mixed

Input connector pair 1/2 is set to «Analog», an analog 2-channel audio signal is accepted by inputs 1 and 2.

Input connector pair 3/4 is set to «Digital», a digital 2-channel audio signal is accepted by input 4.

A3 by input 3 is not available.


Locking to either 48 or 96 kHz is indicated below . In this case, the sync source is input 4.


### Clocking

To keep latency as short as possible, the system does not utilize non-clocked (asynchronous) Sample Rate Converters (SRC).

The clock of the digital audio system is derived from an internal crystal oscillator with a sampling rate of 96 kHz. Alternatively, the clock can be derived from a signal fed to the digital inputs. The sampling rate of this signal must also be 96 kHz. The derived clock is PLL filtered to avoid possible jitter.

It is also possible to use a signal with a sampling rate of 48 kHz as it is in even proportion to the required 96 kHz. In this case, the system detects the sampling rate and automatically doubles it using a synchronous sampling rate doubler to achieve the required 96 kHz. The required filtering is calculated using linear phase FIR filters.





### 9.3. Output

Selecting the «Output» tab allows you to assign the appropriate Output mode to a pair of amplifier output channels (AMP A/B and/or AMP C/D).

The following Output modes can be assigned to a pair of amplifier output channels (AMP A/B and/or AMP C/D).

- Dual Channel
- Mix TOP/SUB
- 2-Way Active
- Mixed configurations

⇒ A change of the Output mode must be confirmed. This is done by selecting either the Back (⏪) or the Home (🏠) button.

⇒ The set Output mode will be activated and the corresponding channels will be muted.

**Note:** Changing the Output mode directly affects the available range of loudspeaker setups.

On the Home screen, the selected Output mode is displayed in the header area below the device name.

The channel strips below the Header section change depending on the chosen modes as shown below.



2 x Dual Channel



2 x Mix TOP/SUB



2 x 2-Way Active



Mixed configuration




On the bottom left of the Output screen, the «Speaker» navigation button provides direct access to the ⇒ Speaker setup screen.

### 9.3.1. Output mode

#### NOTICE!

Ensure that the connected loudspeaker type corresponds to the actual output configuration of the D80.




#### Dual Channel mode (A/B, C/D)

The Dual Channel mode is dedicated to d&b fullrange systems (passive systems) and actively driven d&b subwoofers. Both channels of each pair of amplifier channels can be configured for TOP or SUB cabinets independently.

In Dual Channel mode each pair of amplifier output channels (AMP A/B, AMP C/D) acts as a two channel amplifier (stereo amplifier). The amplifier channels are connected to their corresponding output connectors (AMP A to OUT A ...) while the audio input for each amplifier channel can be assigned via the input routing.

Each output connector is wired in parallel using the respective pins for TOP or SUB configurations.

Pin equivalents of NL4 and EP5 connectors in relation to the output mode are listed in the table below.



2 x Dual Channel mode

<b>NL4</b>	SPEAKER OUTPUTS A (B, C, D): 1+/2+ = Amp A (B, C, D) pos. 1-/ 2- = Amp A (B, C, D) neg.
<b>EP5</b>	SPEAKER OUTPUTS A (B, C, D): 1/3 = Amp A (B, C, D) pos. 2/4 = Amp A (B, C, D) neg. 5 = n.c.



### Mix TOP/SUB mode (A/B MIX, C/D MIX)


The Mix TOP/SUB mode allows d&b fullrange systems (passive systems) and actively driven d&b subwoofers to be linked together and connected to the amplifier using a single 4-wire cable.

TOP cabinets (setups) can be selected on channel A (C) and SUB cabinets (setups) on channel B (D).

In Mix TOP/SUB mode both amplifier channels of the corresponding pair (AMP A/B, AMP C/D) are connected to both output connectors (AMP A and AMP B to OUT A and OUT B ...) while the audio input for each amplifier channel can be assigned via the input routing.

Two output connectors (A/B, C/D) are wired in parallel using the respective pins for TOP and SUB configurations.

Pin equivalents of NL4 and EP5 connectors in relation to the output mode are listed in the table below.



2 x Mix TOP/SUB mode

<b>NL4</b>	SPEAKER OUTPUTS A/B (C/D): 1+ = Amp A (C) pos. (TOP) 1- = Amp A (C) neg. (TOP) 2+ = Amp B (D) pos. (SUB) 2- = Amp B (D) neg. (SUB)
<b>EP5</b>	SPEAKER OUTPUTS A/B (C/D): 1 = Amp A (C) pos. (TOP) 2 = Amp A (C) neg. (TOP) 3 = Amp B (D) pos. (SUB) 4 = Amp B (D) neg. (SUB) 5 = n.c.




## 2-Way Active mode (2-WAY)

The 2-Way Active mode is dedicated to d&b active systems.

In 2-Way Active mode both amplifier channels of the corresponding pair (AMP A/B, AMP C/D) are connected to both output connectors (AMP A and AMP B to OUT A and B ... ). The audio input for each pair of amplifier channels can be assigned via the input routing.


All settings of channel A (C) and the corresponding input signal are internally linked to channel B (D).

Pin equivalents of NL4 and EP5 connectors in relation to the output mode are listed in the table below.



**2 x 2-Way Active mode**

<b>NL4</b>	SPEAKER OUTPUTS A/B (C/D): 1+ = Amp A (C) pos. (LF) 1- = Amp A (C) neg. (LF) 2+ = Amp B (D) pos. (MF/HF) 2- = Amp B (D) neg. (MF/HF)
<b>EP5</b>	SPEAKER OUTPUTS A/B (C/D): 1 = Amp A (C) pos. (LF) 2 = Amp A (C) neg. (LF) 3 = Amp B (D) pos. (MF/HF) 4 = Amp B (D) neg. (MF/HF) 5 = n.c.




### Mixed configurations

As the output mode is assigned to a pair of amplifier channels (AMP A/B, AMP C/D) mixed configurations such as ...:

- AMP A/B ⇒ Dual Channel, AMP C/D ⇒ 2-Way Active
- AMP A/B ⇒ Dual Channel, AMP C/D ⇒ Mix TOP/SUB
- AMP A/B ⇒ Mix TOP/SUB, AMP C/D ⇒ 2-Way Active





... as well as all other combinations are also possible.



### Mixed configuration example

AMP A/B ⇒ Dual Channel, AMP C/D ⇒ 2-Way Active





## 9.4. Remote

Selecting the «Remote» tab allows you to assign remote settings for both Ethernet and CAN remote control.

Selecting the navigation field «IP settings» enters the corresponding subscreen. In addition the IP mode is displayed at the bottom right of the field.

### 9.4.1. IP settings

#### IP address

Selecting either field opens the numerical input mask and allows you to enter the relevant data.

#### IP mask

#### IP gateway

Wrong entries can be corrected by tapping the Erase button (X) on the bottom right.

Tapping «OK» on the top right confirms the entry, closes the input mask and switches back to the Remote screen.

Tapping the Back button (←) on the top left cancels any entry and switches back to the Remote screen keeping the previous entry.

#### Set gateway to default

Selecting this button the gateway address will be derived from the IP address and IP mask settings.

#### IP mode

Selecting the field allows the following settings:

##### Auto (DHCP)

When the device is connected to a network with a DHCP server present, a matching IP address will be assigned automatically.

##### Manual

Allows the manual assignment of IP settings.

### Additional information fields

#### MAC:


Displays the fixed MAC address of the device.

#### Conn.:

Shows which of the etherCON connectors is connected (busy).

#### Status:

Provides status information on the network.




### 9.4.2. Remote ID

Selecting the «Remote ID» button allows the setting of the unique Remote identifier of the respective device in the format [nn].[nn].

#### Subnet

The first two digits represent the subnet.



Within an **Ethernet network** up to 100 subnets can be defined (values 0 to 99).


Within a **CAN network** up to eight subnets can be defined (values 0 to 7).

**Note:** In case of a Subnet mismatch the following message is issued at the bottom of the screen:

Remote ID exceeds 7.63, CAN disabled!

#### Device ID

Using the two digit device ID for each subnet, you can define a total of 63 devices (values 1 to 63).




### 9.5. More

Selecting the «More» tab provides further subscreens such as:

- Preferences
- Info
- Levels
- Mains current limiter
- ...

#### 9.5.1. Preferences

Selecting «Preferences» opens the corresponding subscreen with the «Display» tab being active.



### 9.5.1.1. Display

The «Display» tab provides the following display options.

#### Backlight

Enables the following optional settings:

- Off** The display brightness is set to 1 (minimum brightness).
- On** The backlight is permanently on.
- Timeout 10s** The display is illuminated when the encoder is pressed or when the display is touched. The light switches off automatically 10 seconds after the last operation.

**Note:** This setting is recommended to increase the lifetime of the display.

#### Brightness

Enables adjustment of the display brightness in the range from 1 to 10. The default setting is 8.

#### Touch beep

Enables or disables the beep sound when using the touch screen.

#### Touch screen calibration


Due to mechanical impact or the aging process of the touch screen, its calibration references may change.

An indication is that when you tap a specific button and the adjacent button is activated instead or when a specific button does no longer work.

In such cases, the touch screen should be recalibrated.

To calibrate the touch screen, proceed as follows:

1. Select «Touch screen calibration».
  - ⇒ The Screen calibration menu will open guiding you through the calibration process.
2. Follow the relevant on-screen instructions.



### 9.5.1.2. Lock

Selecting the «Lock» tab opens the corresponding subscreen which enables different protection settings.

#### Mode


Selecting «Mode» toggles between two options to protect the device against unintentional operation.

**Press knob 2s** Prevents accidental operation by locking the front panel controls.

**Password** Enables password protection to prevent operation by unauthorized persons.

#### Screen

Selecting «Screen» allows two different settings for the screen when the device is locked.



**Home screen** Switches to the Home screen.

**Levels** Switches to the Levels screen.

### Edit password

Selecting the «Edit password» option opens an input mask which enables you to edit or assign a password (upper-case characters with a maximum length of 7 characters).

Wrong entries can be corrected by tapping the Erase button on the bottom right (X).

Tapping «OK» on the top right confirms the entry, closes the input mask and switches back to the Lock screen.

Tapping the Back button (◀) on the top left exits the input mask and leaves the previous password unchanged.

**Note:** The factory default password is: DBAUDIO

### Lock

Tapping the «Lock» button confirms any new settings and exits the subscreen. A corresponding message is displayed.

The device will be switched to the screen selected for Lock mode.


### Unlocking the device

If you attempt to change the status of the device while it is in Lock mode, the following message will be issued: Press encoder for 2s to unlock. To unlock the device, proceed as follows:

**Press ...** Press and hold the encoder for a minimum of 2 seconds until the message disappears.

- Password**
1. Press and hold the encoder for a minimum of 2 seconds until the corresponding input mask is displayed.
  2. Enter the password as described above. An incorrectly entered password will revert the device to the screen displayed for Lock mode.

If the password is lost or forgotten, a locked device can be unlocked by performing a system reset.




**Note:** All device preferences will be set to factory defaults except for the network (CAN/Ethernet) and fixed device settings.

If you execute this procedure, no dialog will be prompted and the reset will start immediately.

1. Switch off the device.
2. Press and hold the encoder and repower the device.  
⇒ Long confirmation beep.
3. Release the encoder and briefly press the encoder again within 2 sec.  
⇒ Short confirmation beep.  
The device will boot up and will switch to the Home screen. A corresponding message will be issued:

All device settings have been cleared



### 9.5.1.3. Preferences/More

Selecting the «More» tab opens the corresponding subscreen which provides the following options.

#### Buzzer

Enables the following settings:


- Off**            The internal buzzer is switched off.
- On**             The internal buzzer is switched on and serves as an acoustic signal in case of a device or channel error.
- Single**        The internal buzzer generates an intermittent single tone.
- Melody**        The internal buzzer generates a predefined sequence of tones.

#### Set clock

Enables setting the internal clock while the current UTC (Coordinated Universal Time) date and time are displayed at the bottom of the screen.

Within a Remote network, the device's clock is synchronized with the connected PC.





### 9.5.1.3.1. System reset

Selecting «Clear all device settings to default» resets all device settings to factory defaults except for the network (CAN/Ethernet) and fixed device settings.

To prevent accidental reset when you tap the «Clear...» button, a dialog will pop up prompting you to confirm the reset or cancel the sequence by tapping the Back button (⏪).



### Alternative procedure


A system reset can also be triggered as follows:

**Note:** All device preferences will be set to factory defaults except for the network (CAN/Ethernet) and fixed device settings.

If you execute this procedure, no dialog will be prompted and the reset will start immediately.


1. Switch off the device.
2. Press and hold the encoder and repower the device.  
⇒ Long confirmation beep.
3. Release the encoder and briefly press the encoder again within 2 sec.  
⇒ Short confirmation beep.  
The device will boot up and will switch to the Home screen. A corresponding message will be issued:

All device settings have been cleared



### 9.5.2. Info

Selecting «Info» provides basic information about the device.





The information provided is mainly intended for service purposes.

Most of the information is static information, for example:

- Various firmware versions (Firmware Core/DSP/PS/AMP)
- Serial number
- Owner

In addition, there is dynamic information about the actual temperatures of... :

- Power supply (Temp. PS)
- The entire power amplifier (Temp. AMP)
- Central Processing Unit (Temp. CPU)



Tapping the «Hardware» button provides further hardware specific information.

### 9.5.3. Levels

Selecting «Levels» opens the corresponding subscreen.

The data area of the levels screen provides the following information (starting at the top left):



- 1st line** Mute status of each channel.
- 2nd line** Loudspeaker setups selected for the individual channels.
- Input** Current input signal levels of the individual channels.
- Output** Current output voltages of the individual amplifier channels.
- Gainred/Headr** Relationship between headroom (Headr) and gain reduction (Gainred) with peak hold for 1 sec.  
 Display ranges:  
**Gainred** 0 dB ⇒ +32 dB.  
**Headr** -32 dB ⇒ 0 dB.
- Impedance** Current load impedance values for the individual amplifier channels.
- Power** Power currently delivered by the individual amplifier channels.
- Temperature** Current temperatures of the individual amplifier channels.
- ISP/OSP** Indicates whether the input signal (ISP) as well as the controller output signal (OSP) of the individual channel are present.

**GR/OVL**

Indicates whether gain reduction (GR) of the respective channel is active or the respective channel is overloaded (OVL).

**Mains/SMPS**

Displays the current mains voltage and frequency, the current mains power consumption in combination with a power limiter LED and the current temperature of the switched mode power supply (SMPS).

**9.5.4. Mains current limiter (MCL)**

Selecting «Mains current limiter» opens the corresponding subscreen.

The D80 features a power limiter which serves to limit the mains current draw whenever the mains current draw threatens to trigger the circuit breaker.

Limiting is done by reducing the sound levels evenly on all channels. This ensures that the tonal balance is kept.

The **Mains Current Limiter** function allows to set the maximum mains current draw of the device within the range of 95 to 50 % of the nominal limit.

The Nominal current limit depends on the mains voltage range: 16 A in high range, 30 A in low range

This may be useful when the onsite conditions require two devices to be operated per phase conductor or if the onsite circuit breaker is not sufficiently dimensioned.

**On/Off**

Activates the additional limiter.

**Mains current limit**

The maximum mains current draw is defined as a percentage value of the nominal current limit, as indicated above and can be set in the range from 95 % down to 50 % in steps of 5 %.

When the MCL is activated, the defined value is permanently displayed on the «Power» button on the Home screen.

**Setting recommendations**

No. of devices	Circuit breaker	MCL setting
1 x D80	13 A @ 230/240 V	80 %
2 x D80	16 A @ 230/240 V	50 %



### 9.5.5. AmpPresets

d&b amplifiers provide AmpPresets which contain all important user settings of the entire device, such as input, output and channel configurations, EQ and delay settings.

Using AmpPresets, a sound system can be operated in different configurations (e.g. "Conference", "Music" or "Emergency Call") without the need of transferring all detailed settings of the devices used.


There are three types of AmpPresets memories (slots):

- User:** Nine (9) AmpPresets which can be accessed locally or via the d&b Remote network. These presets are used to set the complete device to a previously defined configuration for a particular application. They can be named individually.
- Alarm:** Three AmpPresets which can only be accessed via the d&b Remote network. Intended for use in alarm systems to protect the system settings against local modifications.
- Backup:** Three AmpPresets which can only be accessed via the d&b Remote network. Intended for temporary use to back up the current system settings when another AmpPreset is loaded.


Selecting «AmpPresets» opens the corresponding subscreen which provides the functions «Select», «Name», «Recall», «Store» and «Clear».

At the bottom of the screen, the last AmpPreset number loaded is indicated. If any setting has been modified since loading, «(modified)» will be added to the corresponding entry.

- Select:** Provides access to the nine (9) user preset memories (slots) for loading, saving or clearing data.



- Name:** Enables the assignment or editing of a preset name (maximum of 15 characters). The input mask which appears allows either lower-case or upper-case characters by toggling the corresponding button («abc») on the bottom left.
  - Wrong entries can be corrected by selecting the Erase button (⌫) on the bottom right.
  - Selecting «OK» on the top right confirms the entry, closes the input mask and switches back to the AmpPresets screen.
  - Selecting the Back button (⬅) on the top left cancels any entry and switches back to the AmpPresets screen keeping the previous entry.



**Recall:** Recalls the settings of a stored preset.

**Store:** Stores the current amplifier settings to the selected preset memory.

**Clear:** The selected preset memory is cleared and «(empty)» is displayed on the «Name» button.




**Note:** Choosing one of these functions, a corresponding confirmation dialog will be issued to allow either confirmation of the selection or to cancel the action by selecting the Back button (⏪).



### 9.5.6. Scope

The «Scope» function allows basic signal monitoring of the amplifier's output voltage (full color) and output current (light color).



#### Select

**A U, I** Output voltage and current of channel A.

**B U, I** Output voltage and current of channel B.


**C U, I** Output voltage and current of channel C.

**D U, I** Output voltage and current of channel D.

**All U** Output voltage of all channels.

**All I** Output current of all channels.

**All U, I** Output voltage and current of all channels.



#### Y scale

Scale of the measuring values in FS (Full Scale). 1.0 FS represents the maximum output voltage or output current.

#### Application examples


The scope function is a useful tool for ...:

- determining the signal quality.
- determining a phase shift between the channels.
- getting a rough impression of the crest factor.
- checking the output channels (e.g. no output current displayed ⇒ the connector cable may be interrupted or no loudspeaker is connected).
- checking the power amplifier (e.g. no output voltage displayed).

# 10. Channel setup

## Channel setup access chart

Hierarchy level





Selecting a particular channel from the Home screen opens the corresponding Channel setup screen with the respective Channel tab being active.



The Channel setup screen follows the same layout structure as described above and is split into the Header and the Data sections.

Using the tabbed structure of the Channel setup screen provides direct access to the desired function element of each channel.

In addition, the «Channel mute» button of the selected channel as well as the "OSP", "GR" and "OVL" indicators for each channel are available. This allows you to maintain the integrity of the gain structure within the unit while setting up the user definable EQ as well as keeping an eye on the Input routing.



### 10.1. Channel name

Selecting the centered Information field button («Edit channel name») in the header of the Channel setup screen enables you to enter or edit the Channel name (maximum length 15 characters).



The input mask which appears allows either lower-case or upper-case characters by toggling the corresponding button («abc») on the bottom left.

Wrong entries can be corrected by tapping the Erase button (X) on the bottom right.

Tapping «OK» on the top right confirms the entry, closes the input mask and switches back to the channel setup screen.

Tapping the Back button (K) on the top left cancels any entry and switches back to the Channel setup screen keeping the previous entry.



### 10.2. Configuration switches - Filter\_1, \_2, \_3

The type of filters available depends on the selected loudspeaker setup.

Depending on the type of filters, these are available as function buttons or input fields.

The name of the filter is displayed on the top left of the button or field while the On/Off status or the value is displayed on the bottom right. In addition, the On/Off status is also indicated by colors.

Filter_1	Filter_2	Filter_3
Configuration of crossover frequencies for TOP/SUB, e.g. CUT, 100 Hz, Infra ...  <b>Note:</b> CUT in LINEAR setup: - Butterworth 2nd order (12 dB/oct.) - Corner frequency: 110 Hz - Amplifier gain @ 0 dB: 31 dB.	Compensation of listening distance, e.g. HFA, HFC.  HFC: Off, +1 (HFC1), +2 (HFC2). CSA: Cardioid Subwoofer Array.	CPL ⇒ Array-EQ (compensation of coupling effects)  CPL range: -9 dB ... 0 dB (Off): Cut (Lo shelf) 0 dB (Off) ... +5 dB: Boost (65 Hz, Bell)



On the Home screen, the On/Off status or the set values of the Configuration switches are indicated by the entry on the Channel view button of the corresponding channel strip, as shown in the graphic opposite.


**Note:** A detailed description of the filters available for each loudspeaker is given in the relevant loudspeaker manuals.

A detailed description of the CSA function (Cardioid Subwoofer Array) is given in the technical information TI 330 which can be downloaded from the d&b website at [www.dbaudio.com](http://www.dbaudio.com).



### 10.3. Level

Input sensitivity of the respective power amplifier channel or set of channels (depending on the output mode), adjustable within a range of -57.5 dB to +6 dB in steps of 0.5 dB.



### 10.4. EQ - Equalizer


Selecting «EQ» opens the equalizer subscreen of the respective channel.


The graphic opposite shows the location of the equalizer (User EQ) within the signal chain.

The equalizer provides two independent and user definable 16-band equalizers (2 x 16 minimum phase biquad IIR filters, full parametric) and is split into two layers:

⇒ EQ overview,

⇒ EQ layer/curve.





### EQ overview

The upper part of the overview provides the overall frequency response of all filters while «EQ 1» is displayed in red and «EQ 2» in yellow.

Active filters are displayed by continuous lines and the curves are filled with grey color while inactive filters are displayed by dashed lines.

The bottom part of the overview provides the following functions:


**EQ [n] On/Off** Master On/Off switch for the respective EQ.

**Edit** Opens the corresponding subscreen (EQ layer/curve) for editing.

**Clear...** Resets all filter settings of the corresponding EQ.  
To prevent accidental reset when you tap the «Clear...» button, a dialog will pop up prompting you to confirm the reset or cancel the sequence by tapping the Back button (⏪).



On the Home screen, the On/Off status of the equalizer is indicated by the entry «EQ» on the Channel view button of the corresponding channel strip, as shown in the graphic opposite.



### EQ layer/curve

Apart from the overall frequency response, the following functions and status indicators are provided:

**Header section**  
**EQ [n] - On/Off** On/Off status of the corresponding EQ.

This field also acts as On/Off switch for the respective EQ.

**Data section**  
Line by line from left to right:

**Band selector** Allows the selection of a filter band from the Filter band bar using the encoder.



**Filter band bar**



Displays all filter bands that are in use while the number of remaining filter bands is indicated next to the bar on the right.

**Band On/Off** Switches the selected filter band on or off.

**Type**

Depending on the filter type used, 1 to 4 bands may be required for each filter.

The following table lists the available types, their corresponding parameters and the number of filter bands required for the selected type.

Type	Param. 1	Param. 2	Param. 3	Param. 4	Param. 5	No. of filters
PEQ (Parametric EQ)	FRQ	Q (and corresponding bandwidth - BW)	Gain			1
Notch	FRQ	Q (and corresponding bandwidth - BW)				1
HiShlv	FRQ	Slope	Gain			2
LoShlv	FRQ	Slope	Gain			2
Asym (Asymmetric filter)	FRQ 1	Slope 1	Gain	FRQ 2	Slope 2	4

**Parameter ranges and resolutions:****Type**

The available filter types.

**FRQ**

Filter frequency (center/corner frequency), adjustable from 20 Hz to 20 kHz.



On the top right of the «Frequency/FRQ» input field, the increment is displayed as an octave value. When you tap the field for the first time, the frequency increment is set to 1/6 octave. When you tap the field again, you can toggle between 1/6 and 1/96 octave increments.

To confirm the set frequency, press the encoder.

**Q  
BW**

Q of the filter, adjustable from 0.5 ... 25 in 10 % steps.  
In addition, the resulting bandwidth (BW) is displayed as a value (2.0 ... 0.04 octaves) in a non-editable Information field below the Q Input field.

**Slope**


Slope can be set to 6, 12, 18 or 24 dB/octave.

**Gain**

Gain, adjustable from -18 dB to +12 dB in 0.2 dB steps.

**Clear  
band**

Resets all settings of the selected filter band right away.



### 10.5. DLY - Delay

An independent signal delay is available for each channel to allow delay settings of up to 10000 ms/10 sec (3440 m/11286 ft).

#### DLY On/Off

Switches the delay on or off without affecting the entered delay values.

Set to "On" the set value will be applied right away.

#### Value

The delay time is adjustable from 0.3 to 10000 ms in steps of 0.1 ms or a corresponding value depending on the units selected.

#### Unit

Enables selection of the delay units, either milliseconds [ms], meters [m], feet [ft] or seconds [s].

A change in the units will be applied to all channels.

On the Home screen, the "On" status of the delay is indicated by the set value and unit on the Channel view button of the corresponding channel strip, as shown in the graphic opposite.

### 10.6. Input routing

Selecting «Input routing» opens the corresponding subscreen.

The input sources can be selected individually per amplifier channel or pair of amplifier channels (depending on the output mode setting):

1 to 4 input sources can be selected per amplifier channel. The first input source can be selected freely from all available input channels (defined by input mode). The second channel of the subsequent pair must be set to the same type as the first one. Analog and digital inputs can be combined.

#### Example

Analog/ Analog e.g. A1 + A3 (not: A1 + D3).

Digital/ Digital e.g. D1 + D3 (not: D1 + A3).

Analog/ Digital e.g. A1 + A2 (not: A1 + A3); D3/D4 (not: D1 + D3)

**Note:** Attenuation of 6 dB with two or more sources selected.

The input routing is stored for every input mode setting. When the input mode setting is changed from analog to digital mode and back again, the input routing of the analog mode is recovered again.

The Input routing screen also provides direct access to the ⇒ «Input mode» screen.



## 10.7. System check/LM


### 10.7.1. System check

System check is a powerful and convenient tool to check the condition of a complete d&b sound reinforcement system driven by d&b amplifiers. It is preferably used in conjunction with the d&b Remote network and the R1 software.

However, for smaller systems or single cabinets, System check can also be accessed and executed locally.

System check utilizes the amplifier's capability to measure the impedance (Z) connected to its outputs using a sine wave signal created by the DSP section of its controller.

Selecting «System check» opens the corresponding subscreen.



### System check menu

The System check menu provides two buttons to start either a «System calibration» or a «System check» run.

In addition, a table is provided indicating the progress («Status») and the results (Z values) for both the calibration («Calib.:») and the check («Check:») runs.

The column header of the table for the Z values changes according to the connected loudspeaker cabinet, provided the respective loudspeaker setup is loaded.

**Status** Brief indication of the current status of the calibration or check process. In case of an error the status is indicated in red.

**LF** The calibration and check results for the LF section.

**LF®)** The calibration and check results for the rear LF driver of an actively driven cardioid subwoofer, such as the J-SUB or J-INFRA.

**MF** The calibration and check results for the MF section of applicable cabinets.

**HF** The calibration and check results for the HF section.

### System check procedure

The typical procedure using System check is as follows:

1. When the system is fully set up, check and verify all connections.
2. Mute all amplifier channels.
  - ⇒ The correct wiring of the system can now be tested by listening to each channel separately using an appropriate audio program and the MUTE switches - preferably controlled by R1.

3. As a next step, execute a **System calibration**.

⇒ The calibration process identifies the actual load impedances for each channel. The result will be stored as a reference and used to calculate the upper and lower limits for the tolerance band.

To verify the correct connection of cabinets and amplifiers, the calibration result can be compared with the typical impedance values for d&b loudspeakers as listed in the ⇒ Appendix: "Typical impedance (Z) values" on page 76.

4. Run **System check**

⇒ Executing a System check after the event will repeat the measurement and display all values that are outside of the tolerance band, indicating a possible damage to the system components.

When a sound system is repeatedly used in the same configuration for which a calibration file exists, the System check procedure can also be used before the show to verify the system's correct setup.

A System check will only provide valid impedance values, if the amplifier has been calibrated before the check with the load connected or if a valid calibration file has been loaded using R1.

### 10.7.2. Load monitoring (LM)

#### Features

The d&b Load monitoring function is related to the System check function and serves to identify a possible loudspeaker malfunction.

#### Function

The calibration process, performed from the System check menu with the completely set up system, determines the impedance for each channel and calculates the related upper and lower impedance limits.

While the system is operating, d&b Load monitoring continuously monitors the load impedance separately for both frequencies. It detects any changes in loudspeaker impedance and reports an error if the limits are exceeded. For this purpose, Load monitoring uses inaudible pilot signals which are faded in for approximately 2 seconds in user defined intervals.

---

#### NOTICE!



---

The resolution of Load monitoring regarding failures of single components depends on the type and the number of loudspeakers connected to each channel.

The maximum number of cabinets which can be operated in parallel by one amplifier channel in order to be able to detect a failure of a loudspeaker component is listed in the ⇒ Appendix: "Max. number of cabinets operated in parallel" on page 78.

Load monitoring does not work if:

- the amplifier is switched off or switched to standby mode.
  - the respective channel is muted.
  - the pilot signal level is too low.
-



### Load monitoring setup

On the «System check» screen, selecting «LM setup» opens the corresponding subscreen.

The «Load monitoring setup» menu provides all relevant parameters for adjustment to the on-site requirements.

#### Load monitoring On/Off

Activates Load monitoring. The On/Off status is also indicated on the System check and Channel setup screens.

#### LM Period

The maximum time in detents of 20 sec. it takes the system to detect a loudspeaker malfunction. The intervals of the pilot signal are derived from this parameter.

#### LM Threshold

Large signal threshold. When the output signal exceeds this voltage level during the measurement, the tolerance limits for this particular measurement are increased in order to compensate for the reduced accuracy.

#### zMin tolerance

Lower limit of the impedance window, which is set to -20 % by default.

#### zMax tolerance

Upper limit of the impedance window, which is set to +30 % by default.

#### Dev.:

Relative deviation in percent in relation to the reference values determined during calibration.

### 10.8. Speaker

Selecting «Speaker» opens the Speaker setup subscreen which enables the selection of loudspeaker setups for the applicable d&b loudspeakers (depending on the selected output mode).

The setups available are arranged in two blocks, «Series» and «Speaker».

#### Back (⏪)

The Back button provides two options:

1. The selection has not been confirmed by tapping «OK» ⇒ Cancel: Exits the subscreen and the previous configuration remains active.
2. The selection has been confirmed by tapping «OK»: Exits the subscreen.

#### Series

The bottom left of the «Series» Input field displays the number of setups available while the bottom right displays the actual name of the Series.

The list is in alphabetical order, the starting point, however, is the Series currently loaded.

Selecting «(All)» provides direct access to all setups available and the LINEAR setup.

## Speaker

The bottom left of the «Speaker» input field displays the version of the selected loudspeaker setup while the bottom right displays the actual setup name.

The loudspeaker list is either in numerical or alphabetical order depending on the selected series.

When «(All)» is selected in the «Series» field, the list starts with the numeric setup names followed by the remaining setup names in alphabetical order. The starting point, however, is the setup currently loaded.

## OK

Selecting «OK» adjacent to the «Speaker» selection field confirms the configuration and the selected setup will be activated.

## Clear...

To prevent accidental reset when you tap the «Clear...» button, a dialog will pop up prompting you to confirm the reset or cancel the sequence by tapping the Back button (⏪).



Selecting the «Clear...» button clears/resets the following loudspeaker related settings of the respective channel.

- Configuration switches (Filter\_1, Filter\_2, Filter\_3) are reset.
- Level is set to 0 dB.
- Delay settings are reset (the selected unit will be kept).
- All EQ settings are reset.

## Array Processing

For applicable loudspeakers, the «ArrayProcessing» button becomes functional. It indicates the On/Off status of the function and provides direct access to the ArrayProcessing subscreen, which is described in ⇒ Chapter 10.8.1. "ArrayProcessing (AP)" on page 61.

**Note:** ArrayProcessing does not apply to all loudspeakers. When the function is not applicable, this button is not functional.

## LoadMatch

For applicable loudspeakers, the «LoadMatch» button becomes functional. It indicates the On/Off status of the function and provides direct access to the LoadMatch subscreen which is described in ⇒ Chapter 10.8.2. "LoadMatch" on page 62.

**Note:** LoadMatch does not apply to all loudspeakers. When the function is not applicable, this button is not functional.



### 10.8.1. ArrayProcessing (AP)

Usually ArrayProcessing (AP) data are generated within the ArrayCalc software and transferred to the amplifiers via the d&b Remote network (OCA) using R1 V2.


However, once the ArrayProcessing data have been transferred to an amplifier remotely, each data slot may also be accessed locally.

**ArrayProcessing slot** Selection field for each memory slot.


**Note:** The first slot (1) is reserved as a bypass slot.

Below the selection field, the slot name and version are displayed together with the comment for the slot that was previously entered in ArrayCalc.

In addition, the selected slot is indicated on the respective channel strip on the «Home» screen.



**Clear all slots** Resets all slot data.



### 10.8.2. LoadMatch

Selecting «LoadMatch» on the Speaker setup screen opens the corresponding subscreen.

⇒ To activate LoadMatch, tap the On/Off button on the left next to the «Cable length» input field.

For applicable loudspeakers, the d&b LoadMatch function enables the amplifier to electrically compensate for the properties of the loudspeaker cable used. This function, which covers a bandwidth of up to 20 kHz, preserves the tonal balance when cable lengths of up to 70 m (230 ft) are used.

LoadMatch does not require an additional sense wire and is therefore applicable with any connector type used.

To provide optimum compensation, LoadMatch requires the entry of the following three parameters:


**Cable length** Length of the cable in meters in steps of 5 m.  
 ⇒ The corresponding length in "ft" is displayed on the bottom left of the input field.




**Speaker count** Number of cabinets connected.

**Cross-section** Cross section in square millimeters (mm<sup>2</sup>) in steps of 0.5 mm<sup>2</sup> up to a maximum of 10.0 mm<sup>2</sup>.  
 ⇒ The corresponding "AWG" value is displayed on the bottom left of the input field.  
 ⇒ The resulting cable impedance is shown as an ohmic value in the «Cable impedance» information field underneath.

### Maximum gain reached

Depending on the LoadMatch settings, the message «Maximum gain reached» indicates the limit up to which the LoadMatch function works.





### 10.8.3. LINEAR setup

In addition to the loudspeaker specific setups, a LINEAR setup is also available allowing the D80 to be used as a linear power amplifier.

**Note:** CUT in LINEAR setup:

- Butterworth 2nd order (12 dB/oct.)
- Corner frequency: 110 Hz
- Amplifier gain @ 0 dB: 31 dB.

### 10.9. Frequency generator - Freq. gen.

Selecting «Freq. gen.» opens the corresponding subscreen.

Each amplifier channel is equipped with an independent signal generator offering sine wave or pink noise signals.

The generator provides pure-spectral sine wave signals with high frequency accuracy and free of harmonics.

The generator can be used to check the connected loudspeakers or to identify room resonances, for example.

The generator is inserted in the signal path after the input section and before the actual signal processing. The test tone will sum up with any input signal present.

**Note:** As a precautionary measure, the frequency generator is always set to Off after the device is powered on.

#### Off

The frequency generator is switched off (Bypass).

#### Sine/ Pink noise

To turn the frequency generator on, select either «Sine» or «Pink noise», depending on the desired signal.

#### Frequency

The frequency is adjustable from 10 Hz to 20 kHz.



On the top right of the «Frequency/FRQ» input field, the increment is displayed as an octave value. When you tap the field for the first time, the frequency increment is set to 1/6 octave. When you tap the field again, you can toggle between 1/6 and 1/96 octave increments.

To confirm the set frequency, press the encoder.

## Level

The level in dBu is adjustable from  $-57.5$  dB to  $+6$  dB in  $0.5$  dB steps.

The level value corresponds to the level at the controller signal input. The actual output voltage depends on the channel input gain, the frequency dependent gain of the selected loudspeaker setup and the EQ settings, if applicable.

On the Home screen, the On/Off status of the generator is indicated by the entry «FG» on the Channel view button of the corresponding channel strip, as shown in the graphic opposite.





## 11. Web Remote interface

In addition, a Web Remote interface is integrated which provides direct access to the user interface of a single amplifier using a standard web browser.

**Note:** The user interface of the amplifier can only be accessed after connecting the amplifier to a computer via Ethernet. It is possible to connect the computer and the amplifier directly, however, this requires to manually set static IP addresses.

For this reason, the use of a router with DHCP server is recommended for setting up the network connection. If the router also provides a wireless access point, the amplifier may also be controlled using mobile devices.

### Recommended and tested browser

**Windows:** Firefox V 7.0 or higher  
Internet Explorer: None

**OSX:** Safari V 5.0 or higher  
Firefox V 7.0 or higher  
Internet Explorer: None

**iOS:** iOS 6 or higher

**Android:** Mobile Firefox V 27.0 or higher

### Remote control

To enable remote control via the Web Remote interface, proceed as follows:

1. Establish a connection between the etherCON connector of the amplifier and the router.  
⇒ Up to three (3) amplifiers may be daisy chained to connect to one single port of the router.  
After a while, the «Remote» tab of the amplifier screen will display the IP address the DHCP server has assigned to the device.
2. Type this address into the address field of the browser or the mobile device that is connected to the network.  
⇒ In this case: **192.168.11.194**
3. For multiple amplifiers, open one browser tab for each amplifier connected and apply the corresponding IP address.

### Web Remote interface page

The Web Remote interface page is split into three tabs: the «Web Remote», the «Event log» and the «Commands» tabs.



#### Web Remote

The «Web Remote» tab shows the actual screen of the connected amplifier.

All screens and screen items can be accessed in the same manner as on the touch screen by simply clicking the relevant screen item.

The refresh rate can be set to fast or slow.

**Refresh fast** Refresh rate is 1 second.



## Refresh slow

Default setting: Refresh rate is 30 seconds.  
This setting is recommended for larger amplifier networks in order to minimize network traffic.  
However, when you click any screen item, the screen will be refreshed within 1 second.

To change the value of an input field such as CPL, Level, Delay time, EQ settings or Speaker setup, proceed as follows:

1. Click the appropriate field and change the value using the «Value +»/«Value -» buttons.  
As an alternative, values can also be adjusted using the wheel mouse.  
⇒ Simply select the appropriate field and adjust the value using the wheel.
2. To confirm the set value, click the relevant field again or click the respective «OK» button.
3. To change/enter a device or channel name as well as IP settings, click the relevant screen item.  
⇒ An input mask will be displayed which allows you to enter the desired data by clicking the respective characters and/or numbers.
4. Confirm your entry by clicking the corresponding «OK» button.

## Keyboard entries

In addition, entries such as Device name or Channel name as well as IP addresses can also be entered using the keyboard.  
However, depending on the behavior of the browser or its settings, some characters may be not accepted or may change the focus.

## Event log

The «Event log» stores a maximum of 10000 records. Once the maximum number of records is reached, the system starts deleting the first ones ⇒ Ring buffer.

The number of records displayed depends on the size of the browser window.



Located on the right-hand side of the record list are various Navigation buttons allowing you to scroll through the list using the «Page Up/Down» or «Line Up/Down» buttons or by directly jumping to the «Latest» record.

In addition, the editable «Record» field allows you to enter a dedicated record number. The corresponding record will be displayed at the very bottom of the record list.

## Storage option (Save)


In addition, a storage option is provided which allows you to store the Event log data locally. This is mainly intended for service and/or troubleshooting purposes.

To save the Event log data locally, proceed as follows:


Record	Date + time (UTC)	Type	Text no.	Text
224	00 000 0000 00:00:00,000	0		(empty)
225	00 000 0000 00:00:00,000	0		(empty)
226	00 000 0000 00:00:00,000	0		(empty)
227	00 000 0000 00:00:00,000	0		(empty)
228	00 000 0000 00:00:00,000	0		(empty)
229	00 000 0000 00:00:00,000	0		(empty)
230	00 000 0000 00:00:00,000	0		(empty)
231	00 000 0000 00:00:00,000	0		(empty)
232	00 000 0000 00:00:00,000	0		(empty)
233	00 000 0000 00:00:00,000	0		(empty)
234	00 000 0000 00:00:00,000	0		(empty)
235	00 000 0000 00:00:00,000	0		(empty)

Capacity: 10000 records, latest record no.: 0  
Current time on device: 14 Apr 2000 01:00:16 UTC


1. Select the «Save» button at the bottom right corner of the web browser window.  
 ⇒ A corresponding dialog will pop up providing you with a drop-down list from which you can select either the number («Last [n]») of records or «All» records to be saved.



2. Choose the desired option from the drop-down list and select «Save».  
 ⇒ The event log data will be downloaded and the download progress will be displayed.





Once the download is completed, a corresponding message will be displayed.



3. Select «Save» to store the Event log data locally.  
 ⇒ Your web browser will display the corresponding dialog and the file will be saved as **Event.log** to the local download directory you have specified in the download settings of your browser.

### Commands

This functionality is intended for service purposes only



### Licenses and Copyright

Selecting the d&b logo at the top left opens the «Licenses and Copyright» information page.

## 12. Operation (Hardware references)

### 12.1. Power supply

The device utilizes a switch mode power supply with active Power Factor Correction (PFC) and automatic mains range selection.

The power supply is equipped with mains voltage monitoring, overvoltage and undervoltage protection as well as an inrush current limiter.

#### 12.1.1. Active Power Factor Correction (PFC)

The active Power Factor Correction provides a clean and highly efficient sinusoidal current draw, thus providing highest performance under adverse mains conditions or when very long power cabling is necessary.

The power factor is above 0.9 for mains power consumption values of 500 W or higher.

#### 12.1.2. Automatic mains range selection

The automatic mains range selection enables the device to be used with any mains supply worldwide without the need for manual action.

<b>High range</b>	208 - 240 VAC
<b>Low range</b>	100 - 127 VAC

#### Nominal mains ranges

#### Behavior with fluctuating mains voltages

With mains voltages other than the nominal voltages specified above, the device switches to the adequate mode for either 'Protection' or 'Operation'.

The voltage thresholds are dependent on the slope of the mains voltage change.

**Undervoltage**      The Main Power Supply is switched off. In  
**Undefined**        undervoltage state, the auxiliary mains  
**Overvoltage**      supply for device control only operates to a  
                                  limited extend.

0	←	75	←	133	←	170	←	266	←	┌ 400	
<b>Undervoltage</b>		<b>Low range</b>		<b>Undefined</b>		<b>High range</b>		<b>Overvoltage</b>			
Protection		Operation		Protection		Operation		Protection			
0	└	⇒	85	⇒	140	⇒	190	⇒	276	⇒	400

#### 12.1.3. Mains voltage monitoring

The mains voltage and frequency are recorded by the power supply and can be viewed on screen. Where voltages outside of this range are present, a self-resetting protective circuit responds quickly to isolate the internal Main Power Supply leaving only a supervisory circuit running to monitor the mains voltage. The device accepts mains voltages of up to 400 VAC<sub>RMS</sub> without damage to the device in case of a missing neutral line or running phase to phase.

#### 12.1.4. Mains inrush current limiter

The Main Power Supply is started softly to limit inrush current. Up to two D80 may be powered up at the same time without triggering a line circuit breaker of 13-16 A (230 V) or 30 A (100-120 V) respectively. Inrush current is limited to:

- 13 A<sub>RMS</sub> @ 230 VAC
- 22 A<sub>RMS</sub> @ 120 VAC
- 27 A<sub>RMS</sub> @ 100 VAC

#### 12.1.5. Mains supply requirements

Due to the high power capability of the amplifier, properly dimensioned mains supply installation and distribution are essential.

However, the mains supply benefits from the built-in active PFC (Power Factor Correction) function of the amplifier, which causes an almost ideal (sinusoidal) current shape. Power losses of the mains supply and cables are kept to the lowest possible minimum.

Due to its automatic mains voltage selection, the amplifier can be fed from all usual mains voltages within the rated ranges as stated in ⇒ Chapter 12.1.2. "Automatic mains range selection" on page 68. Within these ranges, the mains voltage does not affect average output power figures due to the built-in regulated power supply. However, the dynamic character of common audio signals may cause short-time power peaks being twice as high as the average values. The resulting higher current draw causes an increased voltage drop on the mains line which may reduce the available output power if it gets too high.

To ensure safe and stable operation, observe the following recommendations and specifications:

- Operate a single amplifier on a 16 A circuit breaker at 208 to 240 V (high range) or on a 30 A circuit breaker at 100 to 127 V (low range).
- Operate the amplifier at a high-range supply (208 to 240 V), if possible. A low-range supply (100 to 127 V) requires a cable cross section that is 4 times higher to achieve comparable power performance.
- When three amplifiers are operated with a three-phase (120°) mains supply, the current on the N (neutral) conductor can be minimized by matching loads and signals between the three devices.
- Keep the supply line as short as possible and its cross section as high as possible, especially when operating the device at 100 to 127 V. Voltage drop at full load (30/15 A at 115/230 V) should not exceed 5 %. For reference specifications, refer to the following table.

<b>Maximum cable length for 5 % voltage drop at 3600 W mains power draw</b>				
<b>Cable cross section</b>	<b>100 V</b>	<b>120 V</b>	<b>208 V</b>	<b>230 V</b>
1.3 mm <sup>2</sup> - AWG 16	Not permitted	Not permitted	21 m/69 ft	25 m/82 ft
1.5 mm <sup>2</sup>	Not permitted	Not permitted	24 m/79 ft	29 m/95 ft
2.1 mm <sup>2</sup> - AWG 14	Not permitted	Not permitted	33 m/108 ft	40 m/131 ft
2.5 mm <sup>2</sup>	Not permitted	Not permitted	40 m/131 ft	49 m/161 ft
3.3 mm <sup>2</sup> - AWG 12	12 m/39.5 ft	18 m/60 ft	53 m/174 ft	64 m/210 ft
4.0 mm <sup>2</sup>	15 m/50 ft	21 m/69 ft	63 m/206.5 ft	78 m/256 ft
5.3 mm <sup>2</sup> - AWG 10	19 m/62 ft	28 m/92 ft	83 m/272 ft	102 m/334.5 ft
6.0 mm <sup>2</sup>	22 m/72 ft	32 m/105 ft	95 m/312 ft	116 m/380.5 ft
8.4 mm <sup>2</sup> - AWG 8	31 m/101 ft	44 m/144 ft	133 m/436 ft	162 m/531.5 ft

### **12.1.6. Generator operation/UPS requirements**

To operate the amplifier using a mains generator or uninterruptible power supply (UPS), observe the following:

- With the D80 amplifier the apparent power figure (VA value) is about the same as the effective power figure (W value).
- Use a generator or UPS that can deliver the maximum power required by the entire system. Assume a short time power draw of 7 kVA per D80. This is particularly important when using a UPS without dedicated short-time overload capability.
- Run the generator or UPS at 220 to 240 V, if available. 50 or 60 Hz is not an issue.

### **12.2. Power amplifiers**

The power amplifiers fitted to the D80 utilize Class D technology similar to a switch mode power supply. Compared to the known linear amplifier concept (Class A, AB, G or H), Class D power amplifiers produce less heat and allow for a compact and light-weight design.

While supplying very high maximum output swing, it maintains high efficiency with any kind of signal and load and runs as cool as possible. Channels share the same power supply and are thermally coupled to provide even higher average power figures when unevenly loaded. TOP/SUB setups and active cardioid subwoofers are cases of typical use. A sophisticated circuit design decreases the impact of the load on the amplifier performance and enables a well defined sound reproduction. A comprehensive set of protection features individually prevents each channel from overload and/or damage/defect. Channels that are not affected will continue to operate, if safely possible.

### 12.3. Cooling fans

Three temperature and level controlled fans are incorporated for cooling the internal components, which allows greater cooling during louder program material. The fan speed is consequently reduced during quieter passages preventing background noise interference. If the unit heats up a «Temp. Warning» is issued and the fans will give full cooling power permanently.

### 12.4. Current/power draw and thermal dissipation

#### Measurement references

**Signal CF 12 dB:** Represents 1/8th of the nominal power.

**Signal CF 9 dB:** Represents 1/4th of the nominal power; power is limited to the nominal line current.

**Continuous (cont.):** Unlimited time. Thermal conditions may affect power figures.

**Maximum (max.):** Values are measured 1 sec. after signal was applied.

230 VAC / 50 Hz / 0.5 Ω Source impedance								
Mode/Signal	Load	Line current $A_{RMS}$	Power factor	Input power W	Output power (sum.) W	Power loss W	Thermal dissipation BTU/hr	Thermal dissipation kCal/hr
OFF	-	0.14	0.08	2	0	2	7	2
Standby	-	0.18	0.26	10	0	10	34	9
Idling	-	0.85	0.83	162	0	162	553	139
Signal CF 12 dB cont.	4 Ω/Ch.	12.50	0.98	2780	2150	630	2150	542
Signal CF 9 dB cont.	4 Ω/Ch.	18.00	0.98	4140	3136	1004	3426	863
Signal CF 9 dB max.	4 Ω/Ch.	24.00	0.98	5500	4000	1500	-	-

208 VAC / 60 Hz / 0.5 Ω Source impedance								
Mode/Signal	Load	Line current $A_{RMS}$	Power factor	Input power W	Output power (sum.) W	Power loss W	Thermal dissipation BTU/hr	Thermal dissipation kCal/hr
OFF	-	0.13	0.08	2	0	2	7	2
Standby	-	0.18	0.25	10	0	10	34	9
Idling	-	0.93	0.82	160	0	160	546	138
Signal CF 12 dB cont.	4 Ω/Ch.	13.80	0.98	2822	2150	672	2293	578
Signal CF 9 dB cont.	4 Ω/Ch.	18.00	0.98	3635	2800	835	2849	718
Signal CF 9 dB max.	4 Ω/Ch.	27.00	0.98	5600	4000	1600	-	-

**120 VAC / 60 Hz / 0.2  $\Omega$  Source impedance**

<b>Mode/Signal</b>	<b>Load</b>	<b>Line current <math>A_{RMS}</math></b>	<b>Power factor</b>	<b>Input power W</b>	<b>Output power (sum.) W</b>	<b>Power loss W</b>	<b>Thermal dissipation BTU/hr</b>	<b>Thermal dissipation kCal/hr</b>
OFF	-	0.09	0.07	1	0	1	3	1
Standby	-	0.17	0.44	9	0	9	31	8
Idling	-	1.57	0.89	168	0	168	573	144
Signal CF 12 dB cont.	4 $\Omega$ /Ch.	25.50	0.98	3000	2150	850	2900	731
Signal CF 9 dB cont.	4 $\Omega$ /Ch.	30.00	0.98	3600	2600	1000	3412	860
Signal CF 9 dB max.	4 $\Omega$ /Ch.	54.00	0.99	6400	4000	2400	-	-

**100 VAC / 60 Hz / 0.2  $\Omega$  Source impedance**

<b>Mode/Signal</b>	<b>Load</b>	<b>Line current <math>A_{RMS}</math></b>	<b>Power factor</b>	<b>Input power W</b>	<b>Output power (sum.) W</b>	<b>Power loss W</b>	<b>Thermal dissipation BTU/hr</b>	<b>Thermal dissipation kCal/hr</b>
OFF	-	0.08	0.07	1	0	1	2	0
Standby	-	0.17	0.50	9	0	9	31	8
Idling	-	1.82	0.91	163	0	163	556	140
Signal CF 12 dB cont.	4 $\Omega$ /Ch.	32.50	0.99	3250	2150	1100	3753	946
Signal CF 9 dB cont.	4 $\Omega$ /Ch.	29.00	0.99	2900	2000	900	3071	774
Signal CF 9 dB max.	4 $\Omega$ /Ch.	55.00	0.99	5500	3500	2000	-	-



### 13.1. Service



#### **CAUTION!** Potential risk of explosion.

The device incorporates a lithium battery which may cause danger of explosion if not replaced correctly.

- Refer replacement only to qualified service personnel authorized by d&b audiotechnik.
- Only replace with the same type of battery.

Do not open the device. No user serviceable parts inside. In case of any damage do not operate the device under any circumstances.

Refer servicing only to qualified service personnel authorized by d&b audiotechnik. In particular if:

- objects or liquids have entered the device.
- the device does not operate normally.
- the device was dropped or the housing is damaged.

### 13.2. Maintenance and care

During normal operation, the amplifier provides maintenance-free service.

Due to the cooling concept, no dust filters are required. As a result, filter exchange or cleaning is not necessary.

After a certain period of time, the touch screen may require cleaning or calibration.

For this purpose, proceed as follows:


#### 13.2.1. Touch screen cleaning

If the touch screen requires cleaning ...:

- use a soft cloth only.
- do not use any solvent cleaners.

For cleaning very heavy dirt on the panel, it may be helpful to use a special cleaning spray for TFT screens. In this case proceed as follows:

1. Spray on the soft cloth before wiping the screen.  
⇒ Never apply/spray directly on the screen as the liquid could penetrate the device.
2. Wipe the screen with moderate pressure.



### 13.2.2. Touch screen calibration

#### Indication

Due to mechanical impact or the aging process of the touch screen, its calibration references may change.


An indication is that when you tap a specific button and the adjacent button is activated instead or when a specific button does no longer work.

In such cases, the touch screen should be recalibrated.

#### Calibration

To calibrate the Touch screen proceed as follows:

1. From the «Home screen» go to "«Device setup» ⇒ «More» ⇒ «Preferences» ⇒ «Display»".
2. Select «Touch screen calibration».  
⇒ The Screen calibration menu will be opened guiding you through the calibration procedure.
3. Follow the on screen instructions respectively.





### 14.1. EU declaration of conformity (CE symbol)

This declaration applies to:

#### **d&b D80 Amplifier, Z2710**

manufactured by d&b audiotechnik GmbH.

All products of type D80 starting from variant Z2710.000 are included, provided they correspond to the original technical version and have not been subject to any later design or electromechanical modifications.

We herewith declare that said products are in conformity with the provisions of the respective EC directives including all applicable amendments.

A detailed declaration is available on request and can be ordered from d&b or downloaded from the d&b website at: [www.dbaudio.com](http://www.dbaudio.com).

### 14.2. WEEE Declaration (Disposal)

Electrical and electronic equipment must be disposed of separately from normal waste at the end of its operational lifetime.

Please dispose of this product according to the respective national regulations or contractual agreements. If there are any further questions concerning the disposal of this product, please contact d&b audiotechnik.

### 14.3. Licenses and Copyright

This device includes software components released under different open source licenses. These components are supplied together with the d&b firmware.


A list of the components and a full-text version of all licenses and copyrights can be accessed using the amplifier's Web Remote interface as described in ⇒ Chapter 11. "Web Remote interface" on page 65.

⇒ Selecting the d&b logo at the top left of the «Web Remote» interface page opens the «Licenses and Copyright» information page.

This page provides an overview of the open source software used in this product. As required by the GPL and LGPL licenses, we will send you a copy of the used source code on request. If you would like to obtain a copy, please contact us by mail to:

d&b audiotechnik GmbH  
Eugen-Adolf-Strasse 134, D-71522 Backnang, Germany  
T +49-7191-9669-0, F +49-7191-95 00 00, [info@dbaudio.com](mailto:info@dbaudio.com)

or by email at: [software.support@dbaudio.com](mailto:software.support@dbaudio.com)



## 15.1. System check - References

### Typical impedance (Z) values

The following table indicates typical impedance values in ohms for d&b loudspeakers. With correct measurement conditions and relatively short cables, measured impedances should be within a range of  $\pm 20\%$  of the values indicated in the table.

The values refer to a single cabinet. When two cabinets are connected in parallel, the total impedance is halved, with three cabinets it will be a third and so on.

**Note:** Please note that the LF values were determined by the amplifiers' measurement algorithms using sine wave signals. A DC resistance measurement using a multimeter may produce different results.

D80 amplifiers apply audible low level signals in the Low frequency range for a few seconds using dedicated frequencies for each cabinet type. This reduces the impact of ambient temperature and mechanical aging of the driver components on the impedance values.

System	Z LF	Z HF	Z MF/LF rear
16C	7.5	12	-
24C	12	11	-
24C/CE	7	11	-
10AL/10AL-D	17	13	-
10S/S-D/A/A-D	17	13	-
12S/S-D	7	11	-
12S-SUB	8	-	-
18S/A-SUB	6.5	-	-
27S/A-SUB	5	-	-
4S	17	11	-
5S	16	11	-
8S	10	15	-
B1-SUB	4.5	-	-
B2-SUB	3.5	-	-
B4-SUB	5	-	-
B6-SUB	6.5	-	-
C3	8.5	4	-
C4-TOP	11	12	-
C4-SUB	6.5	-	-
C6/690	9	15	-
C7-TOP	7	8	-
C7-SUB	6	-	-
Ci-SUB	-tbc-	-	-
Ci45/60/90	7.5	13	-
Ci80	11	16	-

<b>System</b>	<b>Z LF</b>	<b>Z HF</b>	<b>Z MF/LF rear</b>
E0	12	11	-
E12/12-D	7	13	-
E12-SUB	8.5	-	-
E12X-SUB	7.5	-	-
E15X-SUB	7	-	-
E3	16	21	-
E4	17	11	-
E5	16	12	-
E6	24	20	-
E8	13	16	-
E9	9	13	-
F1222	8.5	15	-
J8/J12	5.5	15	8
J-SUB	3	-	6
J-INFRA	2.5	-	4.5
M2	3.5	8	-
M4	7	13	-
M6	8	13	-
MAX	7	15	-
MAX2	6.5	15	-
MAX12	7.5	14	-
Q1/7/10	7	12	-
Q-SUB	6.5	-	-
T10	14	16	-
T-SUB	6.5	-	-
V8/12	8	18	-
V-SUB	5.8	-	-
Y7P/10P	9	20	-
Y8/12	10	20	-
Y-SUB	6.5	-	-

### 15.2. Max. number of cabinets operated in parallel

The following table indicates the maximum number of cabinets which can be operated in parallel by one amplifier channel in order to be able to detect a failure of a loudspeaker component.

**Note:** The thresholds of the System check function defined by the light blue area (-20 % ... +30 %) are also used by Load monitoring to evaluate the system status. Therefore the values in the table also apply to Load monitoring. If more cabinets are operated in parallel, a correct supervision for single component faults is not possible. This is of particular importance for voice alarm and evacuation systems.

System	Failure mode				
	Single cabinet disconnected	HF section of single cabinet	Single HF/MF driver	LF section of single cabinet	Single LF driver
16C	3	3	-	1	-
24C	2	2	-	1	-
24C-CE	1	1	-	1	-
10AL/10AL-D	3	3	-	3	-
10S/S-D/A/A-D	3	3	-	3	-
12S/S-D	2	2	-	2	-
12S-SUB	3	-	-	3	-
18S/A-SUB	3	-	-	3	-
27S/A-SUB	1	-	-	-	1
4S	3	2	-	3	-
5S	3	2	-	3	-
8S	3	2	-	3	-
B1-SUB	1	-	-	-	1
B2-SUB	1	-	-	-	1
B4-SUB	2	-	-	2	1
B6-SUB	2	-	-	2	-
C3	2	2	1	2	1
C4-TOP	3	2	-	3	-
C4-SUB	3	-	-	3	-
C6/690	3	2	-	2	-
C7-TOP	3	2	-	3	-
C7-SUB	3	-	-	3	-
Ci-SUB	3	-	-	3	-
Ci45/60/90	3	2	-	3	-
Ci80	3	1	-	3	-
E0	3	2	-	3	-
E12/12-D	3	2	-	3	-
E12-SUB	3	-	-	3	-
E12X-SUB	3	-	-	3	-

System	Failure mode				
	Single cabinet disconnected	HF section of single cabinet	Single HF/MF driver	LF section of single cabinet	Single LF driver
E15X-SUB	3	-	-	3	-
E3	3	2	-	3	-
E4	3	2	-	3	-
E5	3	2	-	3	-
E6	3	2	-	3	-
E8	3	2	-	3	-
E9	3	1	-	3	-
F1222	2	2	-	2	-
J8/J12	2	2	2	2	1
J-SUB	1	-	-	1	1
J-INFRA	1	-	-	1	1
M2	2	2	-	2	1
M4	3	3	-	3	-
M6	3	2	-	3	-
MAX	3	3	-	3	-
MAX2	3	3	-	3	-
MAX12	3	3	-	3	-
Q1/7/10	3	3	-	3	1
Q-SUB	3	-	-	3	-
T10	3	2	-	3	-
T-SUB	3	-	-	3	-
V8/12	2	1	1	1	1
V-SUB	2	-	-	2	1
Y7P/10P	2	2	-	2	1
Y8/12	2	2	-	2	1
Y-SUB	2	-	-	1	1

### 15.3. Error messages

The following table lists possible error messages appearing on the display.

<b>Id</b>	<b>Error text</b>	<b>Eventlog text</b>	<b>Description</b>	<b>Location</b>	<b>Possible reasons</b>
10	System error 8	System error 8 (%02Xh, %d)	Unexpected CPU reset	DSP	Software or hardware error
11	System error 128	System error 128 (%02Xh, %d)	Internal I <sup>2</sup> C communication fault	DSP	Any I <sup>2</sup> C device defect
15	Unknown device type	Unknown device type	Unknown device type		
16	Invalid device ident	Invalid device ident %d	Invalid hardware configuration	ADDAC, Amp., SMPS	Missing or wrong module identification
17	Invalid CPLD version	Invalid CPLD version %d (minimum required %d)	Invalid CPLD identification	DSP	Missing or wrong CPLD identification
18	Invalid ADDAC ident	Invalid ADDAC board ident %d	Invalid ADDAC identification	ADDAC	Missing or wrong ADDAC identification
19	Invalid display ident	Invalid display board ident %d	Invalid DISPLAY identification	DISPLAY	Missing or wrong DISPLAY identification
20	Program error %u	Program error %d, %d, %d, %d	Program error	DSP	Various
21	Invalid DSP Data	Invalid DSP database (Position %d, Error %d)	Invalid DSP data	DSP	Software error
25	Program error %u	Program error %d: AWL error %d in AWL %d, line %d	Program error	DSP	Various
28	SMPS comm. error	SMPS communication error (status %04X)	SMPS communication fault	DSP, SMPS	DSP or SMPS defect, cable defect
29	SMPS firmware mismatch	SMPS firmware V%d. %02d.%02d not suitable for hardware ident %d	Invalid SMPS configuration	SMPS	SMPS firmware does not match module identification
30	SMPS temp err %d°C	SMPS temperature error %+3d°C (power %uw)	Temp-Off		
31	SMPS overtemp %d°C	SMPS overtemperature %+3d°C (power %uw)	SMPS overtemperature	SMPS	Poor cooling
32	Mains overvoltage %dV	Mains overvoltage (avg %3dV, peak %3dV, status %04X, err %04X)	Mains overvoltage	(External: Mains)	Mains voltage is/was too high
34	Mains undervoltage %dV	Mains undervoltage (avg %3dV, peak %3dV, status %04X, err %04X)	Mains undervoltage	(External: Mains)	Mains voltage is/was too low
35	SMPS error POK	SMPS error POK: timeout while waiting for power-ok signal %ums (PSF %4.1uV, avg %5.1dV)	SMPS startup timeout	SMPS	SMPS defect
36	SMPS restart error	SMPS error: too many restarts (restart count %d)	SMPS restart fault	SMPS	SMPS defect



<b>Id</b>	<b>Error text</b>	<b>Eventlog text</b>	<b>Description</b>	<b>Location</b>	<b>Possible reasons</b>
38	SMPS overcurrent %dA	SMPS Error: overcurrent (I-peak %3dA, avg %3dV, status %04X, err %04X)	Mains overcurrent	(External: Power draw)	Heavy output load
39	SMPS error IAC %dA	SMPS error IAC (I-peak %3dA, avg %3dV, status %04X, err %04X)	SMPS fault	SMPS	SMPS defect
40	SMPS temp. sensor fault	SMPS temperature sensor fault (T1 % +3d;T2 % +3d;T6 % +3d;T7 % +3d)	SMPS temperature sensor fault	SMPS	SMPS defect
41	SMPS DC undervoltage	SMPS DC undervoltage error (I-peak %3dA, avg %3dV, status %04X, err %04X)	Amplifier rail voltage not reached	SMPS, Amp.	Amp. overcurrent or SMPS defect
42	SMPS DC overvoltage	SMPS DC overvoltage error (I-peak %3dA, avg %3dV, status %04X, err %04X)	Amplifier rail voltage exceeded	SMPS	SMPS defect
43	SMPS supply error	SMPS supply error 15V (I-peak %3dA, avg %3dV, status %04X, err %04X)	SMPS 15 V supply fault	SMPS	SMPS defect
44	SMPS error off %dV	SMPS error: power supply went unexpectedly off (avg %3dV, peak %3dV, status %04X, err %04X)	SMPS went unexpectedly off	SMPS, External: Mains	Mains voltage is/was too low or SMPS defect
45	Amp. comm. error	Amp. communication error (status %04X)	Amp. communication fault	DSP, Amp.	DSP or Amp. defect
46	Amp. firmware is too old	Amp. firmware version %4.2d is too old, required is %4.2d	Amp. firmware version is older than required	Amp.	Amp. software error
50	Invalid device para	Channel '%c': invalid device parameters (device ident %d)	Invalid device parameters	DSP	Software error or wrong device type detected
51	Invalid DSP prog %u	Channel '%c' : invalid DSP program %d	DSP program invalid	DSP	Software error
52	DSP boot error	Channel '%c': DSP boot error (DSP program %d)	DSP boot error	DSP	DSP or software error
58	DSP comm. error	Channel '%c': DSP communication error	DSP communication fault	DSP	DSP defect or software error
59	Invalid setup data	Channel '%c': invalid speaker setup (speaker id %d, no. %d, err %d)	DSP invalid setup data	DSP	Software error
61	Invalid FIR filter %d	Channel '%c': invalid FIR filter %d (file version %d)	DSP invalid FIR data	(External: FIR data file invalid)	Software error
79	Amp. firmware mismatch	Amp. firmware V%d. %02d.%02d not suitable for hardware ident %d	Amp. has wrong firmware	Amp.	Amp. firmware does not support the Amp. hardware

<b>Id</b>	<b>Error text</b>	<b>Eventlog text</b>	<b>Description</b>	<b>Location</b>	<b>Possible reasons</b>
80	Amp. ground fault	Amp. ground fault (status %04X, err %04X, %5.1dV, %5.1dV)	Ground fault	External: Wrong speaker connection	Error in speaker wiring, ground connection
81	Amp. supply fault	Amp. supply fault 5 V (status %04X, err %04X, %4.1dV)	Amp. 5 V supply voltage fault	Amp.	Amp. defect
84	Amp. supply fault	Amp. supply fault 12 V (status %04X, err %04X, %4.1dV)	Amp. 12 V supply voltage fault	Amp.	Amp. defect
85	Amp. supply fault	Amp. supply fault GND (status %04X, err %04X, %4.1dV)	Amp. gnd voltage fault	Amp.	Amp. defect
86	Amp. supply fault	Amp. supply fault 230V (status %04X, err %04X, %4.1dV)	Amplifier rail voltage fault	Amp., SMPS	Amp. overcurrent, Amp. or SMPS defect
88	Amp. I <sup>2</sup> C fault	Amp. I <sup>2</sup> C fault (status %04X, err %04X)	Amp. internal communication fault	Amp.	Amp. defect
90	Amp. DC fault	Channel '%c': Amp. DC fault	Amp. detected DC voltage output	Amp.	Amp. defect
91	Amp. overcurrent	Channel '%c': Amp. output overcurrent (power %uw)	Overcurrent on output	(External: Cabling)	Short circuit
92	Amp. temperature error	Channel '%c': Amp. temperature error %d°C (filter temp. %d°C, power %uw)	Amp. temperature error	DSP	Software fault on DSP
93	Filter overtemp %d°C	Channel '%c': Amp. filter over temperature %d°C (power %uw)	Amp. over temperature of output filters	Amp.	Poor cooling
94	Amp. clock fault	Channel '%c': Amp. clock fault (%3dkHz, power %uw)	Amp. clock fault	Amp.	Amp. defect
95	Amp. overtemp %d°C	Channel '%c': Amp. overtemperature %d°C (power %uw)	Amp. over temperature	Amp.	Poor cooling
96	Amp. temp sensor fault	Amp. temperature sensor fault (A %d°C, B %d°C, C %d°C, D %d°C)	Amp. temperature sensor fault	Amp.	Amp. defect
99	Amp. temp warn %d°C	Channel '%c': Amp. temperature warning %d°C (power %uw)	Amp. temperature warning	Amp.	Poor cooling
100	SMPS temp warn %d°C	SMPS temperature warning %d°C (power %uw)	SMPS temperature warning	SMPS	Poor cooling
101	Filter temp wrn %d°C	Channel '%c': Amp. filter temperature warning %d°C (power %uw)	Amp. temperature warning of output filters	Amp.	Poor cooling
120	CAN open error	Could not open CAN interface (error %d)	CAN interface open error	DSP	DSP defect or software error

<b>Id</b>	<b>Error text</b>	<b>Eventlog text</b>	<b>Description</b>	<b>Location</b>	<b>Possible reasons</b>
121	CAN error	CAN error %d (remote flags %02X, dbCan flags %02X)	CAN error	Remote ID (External: CAN cabling),	CAN cabling or multiple Remote IDs
122	CAN warning	CAN warning %d (remote flags %02X, dbCan flags %02X)	CAN warning	(External: CAN cabling)	CAN cabling or multiple Remote IDs

